

Thank you for buying a NorthQ product. Our devices gives you and your family the opportunity to experience *a new way of living*.

This user manual helps you to get *Q-Power* installed. The installation can be performed using PC, Tablet or Smart Phone.

In order to use the **Q-Power** with **HomeManager** you need to have a NorthQ gateway (**Q-Stick**, **Q-Gate** or **Q-Gate Pro**).





.Q-Power Installation

The **Q-Power** is the device which is attached to your existing **mechanical** or **electronic** power meter. It measures consumption so you can visualize it in your NorthQ **HomeManager** account.















- 5 Insert the **batteries**
- 6 Press the button 3 times

7 Click on **Start Pairing**





- 8 Check if device is paired
- 9 Click on **Next**

O-Power Installation

10 Check if the **Q-Power** is found

If not found, please check our **FAQ section** on **northq.com**

Select your **meter type**

Electronic meters have a flashing LED, mechanical meters have a rotating disc.

Follow the instruction related to your **meter type**: **electronic** (e) or mechanical (m).

. Meter type Mounting the sensor head ✓ O-Power found!

HomeManager will display pictures of various types of meters.



Following steps are for **electronic meters** only.

12e Enter the **impulse factor** for your meter



13e Click on **Next**

On an **electronic meter** the impulse factor is the number of times the LED flashes per kWh. Typically it is either 1000 or 10.000 per kWh - **look for a number of this size on the meter.**



Q-Power Installation

14e Install the **sensor head** on the meter


Please follow the online instructions. Remember to scroll down to see all the instructions and images!



15e Click on **Next**



3 Total value





Q-Power Installation

Following steps are for *mechanical meters* only.

12m Enter the rotation factor for your meter



 $\textbf{\textit{HomeManager}} \ will \ display \ pictures \ of \ various \ types \ of \ meters.$

On a **mechanical meter** the rotation factor is the number of times the disc rotates per kWh. This varies but can be found on the meter - **look for a number marked "rot./kWh"**.





14m Install the **sensor head** on the meter

Please follow the online instructions. Remember to scroll down to see all the instructions and images!








16m Enter the current consumption from your meter.

You **do not** have to enter leading zeros.

17m Click on Finish

WELL DONE!

You have finished installing your **Q-Power** on **mechanical meter**. Your **HomeManager** should now be receiving data from it. Remember that the **Q-Power** transmits data every 15 minutes, so it may take some minutes before you see your first reading.





NorthQ ApS

Strandvejen 157 | 2900 Hellerup | **Denmark email:** support@northq.com | **website:** www.northq.com