



“Breathe the Difference”

Installation guide for POLL-TEX

IMPORTANT- The thread / weave of the screen is made from Spun Polyester. The material is slightly thicker than a normal screen and care is required when installing.

Re-Meshing

- Remove Spline and existing fly screen.
- Lay the frame on a flat surface and drape the mesh over it.
- Cut the mesh allowing at least 2 inch overlap from the outside edge on all four sides the frame.
- Spline- We recommend using Foam Spline. You can purchase this directly from a screening company. Otherwise try your local hardware store. PVC spline can also be used, but you may have to heat the Spline in hot water to make it more pliable so it is easier to manipulate, especially, if you are installing the mesh if the weather is cold.
- SIZE of Spline- can be the same size as your Spline Slot.
- Start about 90mm from the corner and at the opposite end to the one that has the extra allowances for stretching.
- Use the spline roller to press the spline into the slot. It is important to align screen material straight.
- After completing one end, stretch the mesh slightly whilst at the same time inserting the spline into the second continuous side.
- For the 3rd and 4th Side, pre-roll the groove with the spline roller, before rolling the spline into the slot. This will help with the installation.
- Trim the excess with a Sharp Stanley knife.

A professional installer will not have any issues installing the screens. They have the knowledge, tools and experience.

Cleaning & Maintenance

Use a mild pH-neutral detergent and wipe the screens gently with a microfiber glove and use low pressure water to wash or rinse if needed. We recommend cleaning the screens at least twice a year. Before Pollen Peak Season and After Pollen Peak Season.