

# Stone Panel Assembly Instructions

**1**



We measure the surface to decorate and calculate the number of panels required. Each panel is approximately one square meter.

**2**



In the case of dovetailed panels, they will be squared by cutting one dovetailed end off.

**3**



We place the panel on the wall and we drill across the panel marking on the wall with a 3mm drill. 4 to 8 holes per panel would be needed. Preferably in the cavities between the bricks

**4**



We drill in the wall with a drill of 6 or 8 mm right in the places where we have marked previously and we introduce 6 or 8 mm wall plugs. Screw into the wall until flush

# Stone Panel Assembly Instructions

**5**



Fit the panels together, due to their design the insertion is perfect

**6**



We fit, drill and screw all the panels following the steps 3, 4 and 5.

**7**



Once all panels have been fixed on the wall, use the mastic filler and apply it with the help of a application gun and a fine brush (to texture the mastic). All joints and drill holes must be filled.

**8**



The next step is the painting. Once Mastic filler is dry (about 2-3 hours, but it will depends on local weather conditions) paint with a fine brush where we applied the mastic (joints and drill holes). This will be the main colour of the panel. Is the panel requires more than one colour, once the first coat is dry (About 2-3 hours), you have to mix \_ part of water for \_ part of aging paint, subsequently apply with a damp sponge to the boards and holes to match the colour, and immediately passed a damp cloth in order to achieve a flawless final finish, the surplus aging paint can be removed with a rag wet with water.

