

## International DuraStar 4000 Series 2007-2010 WorkStar 7000 Series 2007-2010 TranStar 8000 Series 2007-2010

PART NUMBER: IT-30-09

## PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS VSM G3

All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

TOOLS REQUIRED: Dash Trim Removal Tool (DTRT), T15 torque bit

PARTS INCLUDED: VSM

LOCATION: Left of radio

STEP 1. The dash bezel must first be removed. Place the DTRT in the upper left hand corner of the dash between the dash molding and the dash bezel. See Photo #1. Use the DTRT in a gentle twisting motion around the bezel to release a series of several retainer clips securing the bezel to the dash. Place the dash bezel carefully off to the side.

STEP 2. Locate the four (4) T15 torque screws securing the climate control to the dash. Remove these four screws and gently pull the climate control forward. Place the VSM behind the climate control as shown in Photo #2, making sure to line up the screw holes. Tighten the four (4) torque screws. (There is another screw in the very upper left hand corner of the dash that can also be used as additional support. This screw is not included in all models, however the VSM is designed around this screw for additional support should it exist in your specific truck.)

STEP 3. Place the dash bezel carefully back in place after you have secured the VSM in place. You have successfully installed your VSM.







Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this VSM G3<sup>TM</sup>. Pro.Fit International may not be held liable for any personal injury resulting from accident or improper installation. Pro.Fit International, Inc.® 1335 Eagandale Court, Eagan, MN 55121, Ph: 651.688.3588 or 800.388.0073 Fx: 651.688.9876

