



Ford Freestar (2004-2006)
Mercury Monterey (2004-2006)

PART NUMBER: FO-91-04-L



PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS Pro.Fit Legend.

All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

TOOLS REQUIRED: Dash Trim Removal Tool, 5/64" drill bit and drill, # 2 Phillips screwdriver

PARTS INCLUDED: Pro.Fit Legend, instructions, two (2) #8x1/2" screws

LOCATION: Below air vent.

STEP 1. Insert the Dash Trim Removal Tool behind the right-hand corner of the wood trim bezel, near the passenger door. Gently pry outward to release a retainer clip. Working the tool towards the steering wheel, release all remaining clips. Set bezel aside. **Photo1.**

STEP 2. Hold the Legend against the dash, to the left of the bolt above the radio. **Photos 1 & 2.** Using the Legend as a guide, mark the location of two (2) screw holes. Set Legend aside. Drill two (2) pilot holes at the marked location using a 5/64" drill bit and drill. Align the Legend over the pilot holes, insert two (2) # 8 x 1/2" screws and tighten.

STEP 3. Re-assemble the dash in reverse order. This completes the installation of your Legend.



Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this Pro.Fit Legend. Pro.Fit may not be held liable for any personal injury resulting from accident or improper installation. Pro.Fit International, Inc.® 1335 Eagandale Court, Eagan, MN 55121, Ph: 651-688-3588 or 800-388-0073 Fx: 651-688-9876

