



Toyota Matrix 2009-2011 Pontiac Vibe 2009 MV-25-03-G3



PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS VSM G3

All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

When properly installed, the metal between the ball and 2 small holes is all that is exposed.
(Some exceptions apply).

TOOLS REQUIRED: 5/64" bit and drill, Phillips screw driver, marking pen

PARTS INCLUDED: VSM G3, A Plate, J Stem, three (3) #8 x 1/2" screws

LOCATION: Right of Radio

STEP 1. Open the glove box and place the VSM G3 exactly as pictured in Photo #2. Once the VSM G3 is flush to the dash and in place, use the G3 as a guide and mark the positions of the pilot holes. Remove the VSM G3 and use a 5/64" bit and drill to carefully drill out the marked locations. Be sure not to drill into the dash more than 1/4". Place the VSM G3 over the pilot holes again, as pictured in Photo #2. Secure the VSM G3 to the dash using the provided #8 x 1/2" screws and a Phillips screwdriver. You have successfully installed your VSM G3.

Note: See the Assembly Instructions for G3 Components for additional information.



Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this VSM G3™. Pro.Fit International may not be held liable for any personal injury resulting from accident or improper installation. Pro.Fit International, Inc.® 1335 Eagandale Court, Eagan, MN 55121, Ph: 651.688.3588 or 800.388.0073 Fx: 651.688.9876

Installation Difficulty
● ○ ○ ○ ○
Simple Advanced

© Pro.Fit International, Eagan, MN 2008

View Instruction & Updates
Online at
www.pro-fit-intl.com