



Ford Flex 2009

NS-59-08-G3



PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS VSM G3

All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

**When properly installed, the metal between the ball and 2 small holes is all that is exposed.
(Some exceptions apply).**

TOOLS REQUIRED: Dash Trim Removal Tool (DTRT), 7mm socket and driver, 5/64" bit and drill, marking pen, Phillips driver

PARTS INCLUDED: VSM G3, A Plate, J Stem, one (1) #8 x 1/2" screws

LOCATION: Above and to the Right of Radio Display

Step 1: Place the DTRT in between the wood grain trim piece that runs the length of the dash and above the radio display. **Photo 1.** Begin on the passenger side and use the DTRT in a gentle twisting motion in order to release a series of eight (8) retainer clips securing this trim piece to the dash. Disconnect the two wiring harnesses connected to this trim piece and carefully set the trim piece off to the side.



Step 2: Locate the 7mm bolt above the air vent to the right of the radio and carefully remove this bolt. Place the VSM G3 over this bolt hole just as pictured (**Photo 2**). Make sure the VSM G3 is flush to the dash and secure. When the 7mm bolt has been tightened to the dash and the VSM G3 is secure, use the VSM G3 as a guide and drill out the pilot hole next to the 7mm bolt using a 5/64" bit and drill. Place the #8X1/2" screw in the pilot hole and tighten it to the dash using a Phillips screw driver.



Step 3: With the VSM G3 flush and secure to the dash, begin to place the dash back together in the opposite manner in which it was disassembled. You have successfully installed your VSM G3!



Note: See the Assembly Instructions for G3 Components for additional information.

Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this VSM G3™. Pro.Fit International may not be held liable for any personal injury resulting from accident or improper installation. Pro.Fit International, Inc.® 1335 Eagandale Court, Eagan, MN 55121, Ph: 651.688.3588 or 800.388.0073 Fx: 651.688.9876

Installation Difficulty
 ● ● ○ ○ ○
 Simple Advanced

© Pro.Fit International, Eagan, MN 2009

View Instruction & Updates
 Online at
www.pro-fit-intl.com