



# Dodge Avenger 2008-2010

PART NUMBER: DG-55-08-G3



## PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS VSM G3

All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

When properly installed, the metal between the ball and 2 small holes is all that is exposed.  
(Some exceptions apply).

**TOOLS REQUIRED:** Dash Trim Removal Tool (DTRT), T20 torque bit, 5/64" drill bit and drill, Phillips screw driver

**PARTS INCLUDED:** VSM G3, A Plate, J Stem two # 8 x 1/2" screws

**LOCATION:** Right of the radio

**STEP 1.** Place the DTT between the console and the chrome shifter bezel and being to gently twist until the 4 clips that hold it in place are released. After releasing this bezel, set it aside and remove the cubby compartment in front of the shifter. This is held in place with two (2) clips. Next, the bezel surrounding the entire shift assembly, cubby hole, and the immediate areas to the right and left of the climate control must be removed. Remove this bezel by first placing the DTT between the bezel and the dash molding to the right of the climate control. Gently work open the four (4) clips holding this bezel in place by working the tool in a clockwise rotation from the right of the climate control down around the shifter and back up the left side of the climate control. Carefully set this piece aside.



**STEP 2.** Next remove the bezel surrounding the radio. Place the DTT in the upper right hand corner of the bezel to the right of the air vent. Using a gentle twisting motion, release the eight (8) clips holding the radio bezel in place, moving in a clockwise rotation. Once the clips have been released, disconnect the wiring to the radio bezel and carefully set aside.



**STEP 3.** Remove the four (4) torque screws surrounding the radio with a T20 torque bit. Remove the radio, do not disconnect the wiring, wrap a protective cloth around it, and simply allow the radio to hang out of the way.

**Step 4.** Place the VSM G3 flush to the dash as pictured in picture two (2). Using the VSM G3 as a guide, mark the positions of the pilot holes using a marking pen. Drill out the marked pilot holes using a 5/64" drill bit. Place the VSM G3 over the pilot holes flush against the dash and secure the VSM G3 to the dash with the two provided 8 X 1/2" screws. After the VSM G3 has been secured, assemble the dash in the reverse order it was dismantled. You have successfully installed your VSM G3!



Note: See the Assembly Instructions for G3 Components for additional information.

Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this VSM G3™. Pro.Fit International may not be held liable for any personal injury resulting from accident or improper installation. Pro.Fit International, Inc.® 1335 Eagandale Court, Eagan, MN 55121, Ph: 651.688.3588 or 800.388.0073 Fx: 651.688.9876

**Installation Difficulty**  
● ● ● ○ ○  
Simple Advanced

© Pro.Fit International, Eagan, MN 2008

View Instruction & Updates  
Online at  
[www.pro-fit-intl.com](http://www.pro-fit-intl.com)