

# Toyota Tundra 2014-2019

## PART NUMBER: MZ-58-08-G3

**\*PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS VSM G3\***

All instructions assume a driver's seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

When properly installed, the metal between the ball and the small hole is all that is exposed. (Some exceptions apply).

**TOOLS REQUIRED:** Dash Trim Removal Tool (DTRT), Cordless Drill, Phillips head screw tip

**PARTS INCLUDED:** VSM G3, J Stem, Lock Plate, 2 - #8x1/2 screws

**LOCATION:** Right of Climate Control

Step 1: Using the DTRT pop loose the panel just below the climate controls (Pic1). Do not remove completely, just loose enough for room for your hand to grab the bottom of the climate controls and pull with light pressure to pop retainer clips. No need to disconnect wiring.



Step 2: Place the mount just below the plastic piece that indents in the opening. The mount should be tight to the bottom of this. The mount's 2 smaller holes should line up with the edge of the trim (Pic2). Mark the 2 larger screw holes and drill pilot holes or using cordless drill attach mount using screws provided.



Step 3: Reverse Step 1.



Pro.Fit International, Inc. ® may not be held liable for any damage to a vehicle before, during, or after the installation or removal of this VSM G3. Pro.Fit International may not be held liable for any personal injury resulting from accident or improper installation.

Pro.Fit International, Inc. ® 221 1<sup>st</sup> Street South, Montgomery, MN 56069, Ph: 507.364.7773 or 800.388.0073

### Installation Difficulty



Simple

Advanced

©Pro.Fit International, Inc. Montgomery, Minnesota 2017

View Instructions &  
Updates Online at  
[www.pro-fit-intl.com](http://www.pro-fit-intl.com)