



Ford F-Series Superduty 250, 350, 450, 550 2008-2010

PART NUMBER: FO-72-08-G3



PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS VSM G3

All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

When properly installed, the metal between the ball and 2 small holes is all that is exposed.
(Some exceptions apply).

TOOLS REQUIRED: Dash Trim Removal Tool (DTRT), 7 mm socket and wrench

PARTS INCLUDED: VSM G3, A Plate, J Stem

LOCATION: Right of radio

STEP 1. In the lower left and right hand corners of the dash are two (2) plastic panels held in place by four (4) clips. These panels are to the left and right of the trailer brake controller (Photo #1). Use the DTT in the upper right hand corner of each of these panels and carefully pry the clips open. Carefully remove these two panels and set aside. Behind each panel is a 7 mm bolt holding the dash bezel in place. Remove these two bolts and set aside.



STEP 2. Place the DTT between the dash bezel and the dash molding in the lower right hand corner of the bezel and begin releasing the bezel clips in a clockwise rotation around the entire bezel. Carefully remove the dash bezel and gently lay it down on a protective cloth, you do not have to disconnect the wiring, just simply allow the bezel to hang carefully.



STEP 3. Locate the two 7 mm bolts to the right of the radio and remove. Place the VSM G3 flush to the contours of the radio (Photo #2) making sure that the two holes line up over the radio mounts. Replace the two 7mm bolts back in place securing the VSM G3 in place.



Step 4. Once the VSM G3 is secured and in place, begin placing the dash back together in the reverse order that it was dismantled. You have successfully installed your VSM G3!

Note: See the Assembly Instructions for G3 Components for additional information.

Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this VSM G3™. Pro.Fit International may not be held liable for any personal injury resulting from accident or improper installation. Pro.Fit International, Inc.® 1335 Eagandale Court, Eagan, MN 55121, Ph: 651.688.3588 or 800.388.0073 Fx: 651.688.9876

Installation Difficulty
● ○ ○ ○ ○
Simple Advanced

© Pro.Fit International, Eagan, MN 2008

View Instruction & Updates
Online at
www.pro-fit-intl.com