



JEEP Wrangler (2011-2013)



Part # DG-92-08-G3

PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS VSM G3

All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

TOOLS REQUIRED: Dash Trim Removal Tool (DTRT), 7mm Socket, Phillips screw driver

PARTS INCLUDED: VSM G3 Mounting Bracket, Lock Plate, J Stem Extension

LOCATION: Right of Radio

Step 1: Remove the lining in the top dash tray. Exposed is a 7mm bolt, remove this and set it off to the side.

Step 2: Remove the knee panel underneath the steering wheel. Simply release two retainer clips on the top of the knee panel and then pull up and out in order to release the two L-Feet the bottom of the knee panel. Place the steering wheel as low as it will go. Just to the right and left of the steering column are two 7mm screws that secure the bottom of the dash panel, remove those and set them aside.

Step 3: Remove the bezel that surrounds the radio. This bezel is a singular piece that covers the entire area from the drivers side door, across the drivers instrument panel, and around the radio which includes the air vents and window switches. Start with the DTRT on the left most side of the bezel to the left of the instrument panel. Insert the DTRT between the bezel and the dash molding. Use a gentle twisting motion to release a series of retainer clips securing this bezel to the dash. Work your way carefully around this entire singular piece and remove it out of the way enough to access the upper right hand bolt that secures the radio to the dash.

Step 4: Remove the bolt in the upper right hand corner of the radio and place the VSM G3 flush against the radio as pictured (photo 2). Replace the bolt back through the pilot hole of the VSM G3 and secure the VSM G3 flush to the radio. NOTE: You may bend the arm slightly in order to achieve a tighter fit.

Step 5: Once the VMS G3 is flush and secured, place the dash back together in the opposite way it was dismantled. You have successfully installed your VSM G3!



Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this VSM G3™. Pro.Fit International may not be held liable for any personal injury resulting from accident or improper installation.

Pro.Fit International, Inc.® 314 West 86th Street, Bloomington, MN 55420, Ph: 952.641.4700 Fx: 952.641.4701

Installation Difficulty
 ● ○ ○ ○ ○
 Simple Advanced

© Pro.Fit International, Bloomington, MN 2013

View Instruction & Updates
 Online at
www.pro-fit-intl.com