



Required

1 x 13mm spanner

Step 1



This pack will include: 2x left side chair, 2x right side chair, 2x chair base, 2x chair back, 1x tray, 24 x 80mm bolt, 24 x nut, 24 x washer

Step 2



Insert 6 x M8 bolts into pre-drilled holes on left side of chair.

Step 3



Position chair base onto the 4 lower bolts on the chair legs.

Step 4



Fix washer and nut to secure base to the side.

Step 5



Position the chair back onto the two higher bolts of the chair side.

Step 6



Fix washer and nuts to secure back to the side.

Step 7



Insert 6 x bolt into the pre-drilled holes of right-side of chair.

Step 8



Position the bolts in the right hand side to the pre-drilled holes of back and base then push right-side into position.

Step 9



Fix washer and nut to secure the right-side to back and base. Tighten all nuts with a 13mm spanner.

Step 10



Repeat procedure for the second chair then place tray on the arm of the adjacent chair.