

Throttle-MAXX ARCTIC CAT PROWLER

INSTALLATION INSTRUCTIONS

Tools Needed: 10mm wrench



Step #1: Place throttle-MAXX gas pedal accessory on bottom side of gas pedal. Slide the four bolts face down through aligned factory holes and use 10mm wrench to tighten nuts.



Final Assembly: Double check that all bolts are securely tightened and you're Throttle-MAXX gas pedal accessory is ready for use!