



Thank you for purchasing a Gen 4 4 Runner side PSD.

1. Remove upper coat hook. If dual hook the closest one to the rear. Use 10 MM Socket.
2. Remove cap from forward position in luggage area. This will expose the threaded area for attachment. Remove rear cover, screw at luggage cover bracket.
3. Attach the bent bracket under coat hook. Leave loose for adjustments. The bracket bottom should be facing towards glass.
4. Assemble the Side PSD rack to the upper bracket using 2 Bolts and nuts provided in kit. Leave loose.
5. Place 4.250 spacer in front hole closest to the front of 4 runner using 4.625" 6mm bolt. Use 3.00 spacer at rear of 4 runner with 4.00" 6mm bolt.
6. Tighten upper bracket at .500" 6mm at bracket. Tighten upper support at coat hook. Tighten front and rear bolts.
7. Tighten all bolts and nuts.

Warning this product is not sturdy enough to hold any type of AIR tanks or Fire extinguishers. Please adhere to the warning listed for your safety.