



Dead pedal installation instructions.

1. Remove your old stock plastic pedal. You know the broken one.
2. Remove the white pieces that are left behind.
3. Install the Orange Boxx Fabrication pedal over the studs in the floor. Using the supplied white nylon nuts screw them over studs in the tube. Cap it off with supplied caps.

Enjoy the new pedal.