



Thank you for selecting Orange Boxx Fabrication . The following is to help guide you through the installation of your Side PSD.

Your Side PSD is made from .125 cold roll steel. It can take many years of punishment. Please follow the following instructions .

- A. Remove the nuts from the center of the coat hooks on left side. Save the hooks you will need them.
- B. With the PSD front facing towards you the 1.750 inch long leg goes on the right and the 1.50 derlin rod leg goes on left. Attach them with hardware.
- C. Place the silver block on the upper right side. Run 5/16 2 inch bolts through the PSD into the base plate for the ROTO Pax. Tighten good.
- D. Using 150 mm bolts washer place offset stud in the hook and reattach to wall. Hey you are done after tightening everything down.
- E. Place Decal on outside rear of FJ.

If you have any problems feel free to contact us. 336 337 6311

or Email [darrelc@orangeboxxfabrication.com](mailto:darrelc@orangeboxxfabrication.com)