



Thank you for selecting Orange Boxx Fabrication . The following is to help guide you through the installation of your Console PSD.

Your Side PSD is made from .125 cold roll steel. It can take many years of punishment. Please follow the following instructions .

A. Paint your console PSD your color detail it in the manner you like.

B. Using supplied hardware (.4374-.500) spacers attach them to the inside of the C-Psd using supplied bolts.

C. This is a clamp base console PSD It is made to clamp down instead of drilling into your console. If it does not clamp with enough force just simply bend in more to add more clamping force. Remember once bent it will stay as tight as you want.

If you have any problems feel free to contact us. 336 337 6311

or Email darrelc@orangeboxxfabrication.com