



Thank you for purchasing a MAX side PSD from us. We were happy to design this item for you.

1. Please use a 10 mm Socket and remove the coat hooks from the drivers side area in the rear.
2. Assemble the side plate to main plate. Line up the 3 holes on side.
3. Assemble the MaxSide PSD loosely with L-Brackets in the bottom facing towards the inside wall. Using supplied Spacers between the wall and PSD run the 8 inch bolt through the PSD and through the spacer. This will help locate the area for next step.
4. Screw on the (L) brackets to the bottom of PSD adjust them. Mark holes to drill through using a 1/4 bit into side interior part for bottom attachment.
5. Attach brackets to the base and the base to the interior shelf, Reinsert spacers and tighten down.