



Thank you for purchasing a Gen 4 Back Window PSD

1. In your kit you will receive the
 - A. Rear window PSD.
 - B. 19 self tapping screws.
 - C. Rubber edge gaurd.

2. Have rear window in down postion .

3. Pull window rubber from upper part of inside rear door. Keep it you will reuse it.

4. Place rubber edge seal on bottom edge of rear window PSD . This part keeps the metal edge from rubbing against the plastic interior making noise.

5. Place and get a buddy to hold in place the rear window psd. You Mark 3 holes to hold PSD into place with screws. If you want to you can pre drill holes with a 3/64 bit not included in kit. Seen in **red** circles.

6. After placing rear door PSD rack with screws. Place upper rubber back into place. Your screws are long enough to drill through rubber into door frame. You will end up with one extra screw.

Warning this product is not sturdy enough to hold any type of AIR tanks or Fire extinguishers. Please adhere to the warning listed for your safety.

