



Thank you for selecting Orange Boxx Fabrication . The following is to help guide you through the installation of your Side PSD.

Your Side PSD is made from .125 cold roll steel. It can take many years of punishment. Please follow the following instructions .

- A. Remove the nuts from the center of the coat hooks on left side.
- B. With the PSD front facing towards you the 1.750 inch long leg goes on the right and the 1.50 derlin rod leg goes on left. Attach them with hardware.
- C. Using bolts washer Run through spacers with holes all the way through and reattach to wall. Hey you are done after tightening everything down.
- D. Place Decal on outside rear of FJ.
- E. These **are not** rated to hang Air Tank on them.

If you have any problems feel free to contact us. 336 337 6311

or Email darrelc@orangeboxxfabrication.com