



Thank you for purchasing a Nissan Xterra side PSD.

1. Remove upper hook on the side you are doing install on. Above the window.
2. Remove the Screw from side interior panel behind the rear seat. (Fig 1) Take the screw from that and install the upper bracket from kit with wing nut facing out. Fully tighten.
3. Remove the lower d-ring part at rear door. (Fig 2)
4. Assemble the PSD bracket to the side you are working with to the Door bracket with correct facing letters on bracket together. All Wing nuts facing out and up. Leave all bolts loose for final adjustments. (Fig 3)
5. Using 1" Dia x .375" spacer . Mount door bracket to the shown hole in step 3. ( leave loose)
6. Using 2.5 stepped spacer assemble the front of PSD bracket to wall.
7. Slide rack on upper bolt. strat wing nut to hold in place.
8. Slide lower part of rack onto the bolts sticking out on the bottom part of assembly. place washers over bolts and loosely tighten the knobs.adjust ract so that the top of rack is level with widow.
9. Tighten all knobs. Now tighten all other bolts.
10. Your PSD rack should looking like it does in the pictures. If you want to take the rack out and use in on your back pack or hunting trip simply remove all knobs and carry it with you.

**Warning this product is not sturdy enough to hold any type of AIR tanks or Fire extinguishers.  
Please adhere to the warning listed for your safety.**