



Thank you for selecting Orange Boxx Fabrication . The following is to help guide you through the installation of your Basket Side PSD.

Your Side PSD is made from .125 cold roll steel. It can take many years of punishment. Please follow the following instructions .

- A. Remove the nuts from the center of the coat hooks on left side.
- B. Using hardware provided after painting your Basket PSD attache the backing plate to the base plate.
- C. With the aluminum rods provided attach the base plate to the front PSD plate. This will only go one way. 1 Rod point is offset.
- D. With the PSD front facing towards you the 1.50 inch long leg goes on the right and the 1.750 derlin rod leg goes on left. Attach them with hardware. These are facing with the felt end towards the wall of the FJ.
- E. Using 3.5 inch bolts washer and through hole spacers reattach to wall were coat hooks was in 1st step. Hey you are done after tightening everything down.
- F. Place Decal on outside rear of FJ.
- G. These **are not** rated to hang Air Tank on them.

If you have any problems feel free to contact us. 336 337 6311

or Email orangeboxxfab@gmail.com