



Notes:

- ▲ Insert backset here 2, 2 $\frac{1}{2}$ " or 2 $\frac{3}{4}$ "
- ▲ Centerline of strike is $\frac{5}{16}$ " lower than Centerline of front.
- ▲ Prep for #8 wood or 8-32 machine screw.
- ▲ Thru bolting holes **ONLY** if required. See trim manufacturers standard template for details. Accurate lock's accommodates 1 $\frac{1}{2}$ " to 1 $\frac{11}{16}$ " center to centers and up to $\frac{1}{4}$ " dia. post.
- ▲ If there are any additional questions about the thru-bolting, please contact our office. Knob/Lever holes may vary from different trim manufacturers. Please refer to their templates to confirm these dimensions.

Additional Notes:

- a) **Responsibility:** Door and frame manufacturers are responsible for providing adequate construction or re-inforcement for proper installation of hardware shown.
- b) See catalog / spec sheets for additional lock details



ACCURATE
 LOCK & HARDWARE
 AMERICAN CRAFTED SINCE 1972

Standard 9825ML Magnetic Passage
 Latch - All Backsets

T-ALH.9825ML