

Bike-Quip: Installation Guidelines - Honda ST1300 Windscreen

1. On models with an electric screen – raise the screen to its highest position.
2. Remove the black plastic covers (2 front / 2 rear) taking note of where and how each cover is to be re-fitted.
3. You have now uncovered 4 bolts. Remove all 4.
4. Lightly glue the 2 rubber gaskets on to the windscreen metal brackets (or use double-sided tape).
5. Gently hold the Bike-Quip screen on to the rubber gaskets.
6. Loosely fit the BOTTOM 2 bolts first... and then the TOP 2. This will make the job of 'hole alignment' easier as there is more flex in the top of the windscreen metal bracket when compared with the bottom.
7. Tighten all 4 bolts and replace the 4 black plastic covers.

Ride Safe!