

## **MAZE Changelog**

From V1.1.1 it is possible to see the firmware version in "Settings Mode". It is displayed with dots in the animation on screen. For instance: ". . ." means V1.1.1 and ". : ." means V1.2.1 and so on...

### **V1.2.2 - 02/03/19**

#### **Fixed:**

- Mute deselect was applied to all presets in bank

#### **Added:**

- While morphing LED indicator is magenta, otherwise cyan.

### **V1.2.1 - 13/02/19**

#### **Fixed:**

- Possibility of last preset not being highlighted in Save Mode with Fade sequencing.

### **V1.2 - 08/01/19**

#### **Added/Changes:**

- Fade sequencing method
- Negative triggers for trigger based sequencing methods - Changed triggers only to HIGH
- Adjusted encoder push sensitivity

#### **Fixed:**

- Possible unresponsive 0V in Continuous sequencing
- Pushing matrix holds preset when sequencing first 3 presets in Continuous sequencing

### **V1.1.1 - 29/10/18**

#### **Added:**

- Copy and Delete Banks Menu.
- Hold preset in "Save Mode" to randomise preset.
- "Calibration Menu" retrieve previous setting.
- Screen in "Settings Menu" shows version as dots in animation.

**Fixed:**

- Screen in "Calibration Menu" does not reset.
- "Loud" feedback patch causes keypad to stop working. - Modulating SLCT input in RANDOM or EUCLIDEAN sequencing causes keypad to stop working until mode switch.

**V1.1 - 06/08/18****Added:**

- Deselecting while setting routings will set routing to either zero, previous, current, and then unselects. (this is switchable in settings)
- Trigger for SLCT input can be set to trigger on "HIGH" or "LOW" (So on +5V or 0V, again this is switchable in settings)
- In settings, when switching banks. Display states "Bank 1", "Bank 2" etc. instead of just "Bank". - While changing routings: the LED indicator will turn green for attenuation and red for attenuversion.
- While changing routings: all not selected routing positions will dim brightness. - While changing routings: morph will not influence routings that are being changed.

**Fixed:**

- Slight chance of clearing the bank when pressing the encoder just before going into Settings.