




RIGGING INSTRUCTIONS

RUPP MARINE, INC. • 4761 ANCHOR AVE. • PORT SALERNO, FL
PHONE (866) 477-2678 • (772) 286-5300 • www.ruppmarine.com



DETAIL B
MONO HALYARD
ONLY

DETAIL A
MONO HALYARD
ONLY

LINE 1

LINE 2
Optional

STOP BALL

KNOT (nylon only)

SNAP SWIVEL

OUTRIGGER CLIP (RUPP KLICKER™ SHOWN)

SNAP SWIVEL

DETAIL C
NYLON HALYARD
ONLY

MELT & SPREAD END OF
LINE THRU LINE-LOCK
SWIVEL. USED TO ADJUST
TENSION OF HALYARD
LINE.

DOUBLE PULLEY
used for double rigg.
SINGLE PULLEY used
for single rigg.

BUNGEE CORD
ASSEMBLY

DETAIL D

STRAP EYE IS
MOUNTED ON BOAT

Thread white nylon or "mono" halyard lines through eye bolts of rigger and pulleys as shown. Do not use inboard eye bolt on first spreader. Run LINE "1" to TIP eyebolt "C", for double rig run LINE "2" either as show at eyebolt "A" or further out to eyebolt "B".