

Check the functionality of the generator and other appliances
Make sure all of the equipment is functioning properly (i.e. antennae, solar panels)
Reinstall fuses that may have been removed
Ensure that insurance coverage is valid and up-to-date removing all protective covers.
Air out the interior by opening all the windows and roof vents.
Turn on all of the lights and replace bulbs if necessary.
Remove any pest control items from interior and exterior compartments including hot water
heater, refrigerator gas assembly, and stove top, and oven.
Reinstall batteries in clocks, smoke detectors, etc.
Wash interior with proper cleaners for different surfaces. Vacuum the floors.
Inspect roof and exterior body for signs of damage.
Lubricate hinges, locks, slides, and other moving parts.
If you have an awning roll it completely out. Check for damage, mildew, and insects.
Inspect the headlights, including high and low beams, the taillights, brake lights, and turn signals.
Change all oils and filters along with spark plugs
Ensure the battery is functioning properly
Have the fuel injection system serviced
Have the water system flushed
Flush and replace old antifreeze with proper coolant.
Check for cracks in all hoses and fan belts, replace if necessary.
Remove tire covers and inspect tires for wear and deterioration.
Inflate tires to proper pressure using air compressor for accuracy.
Repack trailer wheel bearings with grease and tighten lug nuts to manufacturer's specifications.
If you have a tow able RV, be sure to examine the hitch systems for wear, loose bolts and cracks.
Open main LP system and check it for leaks.
Clean exterior of your RV
Check and refill your first aid and emergency kits.
Stock up with necessities for cooking, cleaning, and entertaining.
Review kitchen equipment and inventory of favorite games, books, cards, puzzles, CDs, DVDs or
videos.
Call DISHForMyRV (1-800-472-1039) to activate your Pay-As-You-Go service to enjoy TV on the go
Hit the road!