



C Prox Ltd (inc Quantek)

59 Sheffield Road, Dronfield, S18 2GF

+44(0)1246 417113 sales@cproxltd.com www.quantek.co.uk

UKTX003 Programming Instructions

This transmitter is compatible with UKTX003, frequency 418MHz.

Before you can use this transmitter, you must first set the security code so that it is the same as your existing transmitters.

1. Remove the screw located on the back of an existing transmitter and carefully lift off the front. Put the transmitter to one side and do the same on the new transmitter.
2. Locate the row of 10 dipswitches on the new transmitter and adjust their position using the tip of a ballpoint pen so that they match your existing transmitter.
3. Check that you have set the switches correctly. Fit the front and replace the screw. Your transmitter is now ready to use.



CODE SWITCH SHOWING FACTORY SETTINGS