

FURNITURE FINISHES, CARE & WARRANTY

FINISH: OPTION 1

MONOCOAT - Natural Oil Finish

- Plant-based
- Environmentally responsible
- Sustainable, durable
- 100% VOC-FREE
- Water resistant
- Resistant to heat up to 212 °F
- Turns wood darker

FINISH: OPTION 2

TIMBERLIFE - Colour Dip - Clear

- High performance, water-based solid wood finish
- The natural beauty of the wood is enhanced
- Translucent finish.
- Consist of lightfast pigments which will not fade.
- Contains acrylic resins and UV absorbers
- Contain light stabilizers which reduce harmful effects of the sun

TAKING CARE OF YOUR FURNITURE

Dust indoor teak furniture with a dry microfiber cloth. Teak furniture, when left bare and not sanded will fade to a natural silver grey colour. This colour transformation does not affect the durability of the teak furniture or the wood itself. To maintain the smooth finish and golden brown colour, you will need to sand your teak furniture slightly once every five years.

WARRANTY

Our timber products are warranted for 1 year from the date of purchase in respect of frame and craftsmanship. This warranty does not extend to the normal wear and tear associated with products. Claims are subject to assessment by INHABIT and decisions are made at the discretion of INHABIT.