


PUSH-N-GO DUO



Instruction Manual


PLEASE KEEP INSTRUCTIONS FOR FUTURE REFERENCE



Congratulations on Purchasing
your new Love N Care Stroller

Within no time you should be able
to have this stroller ready to
meet your beautiful child :)





PUSH-N-GO PUCO

SAFETY GUIDELINES AND INSTRUCTIONS MUST ALWAYS BE FOLLOWED BEFORE MAKING USE OF THIS PRODUCT. PLEASE RETAIN THESE INSTRUCTIONS FOR FUTURE REFERENCE. READ ALL INSTRUCTIONS CAREFULLY BEFORE ASSEMBLY AND USE OF THIS STROLLER.

THIS PRODUCT COMPLIES WITH PRODUCT SAFETY STANDARD AS/NZS 2088:2009



WARNINGS TO AVOID INJURY OR DEATH

FOLLOW THE MANUFACTURER'S INSTRUCTIONS.

PUT ON ALL THE BRAKES WHENEVER YOU PARK THE STROLLER.

ALWAYS APPLY THE BRAKES WHENEVER THE STROLLER IS STATIONARY.

DO NOT LEAVE CHILDREN UNATTENDED.

SECURE THE CHILD IN THE HARNESS AT ALL TIMES.

DO NOT CARRY EXTRA CHILDREN OR BAGS ON THIS STROLLER.

DO NOT USE THIS SEAT WITH ANY OTHER MODELS OF STROLLER.

MAKE SURE CHILDREN ARE CLEAR OF ANY MOVING PARTS IF YOU ADJUST THE STROLLER, OTHERWISE THEY MAY BE INJURED.

CHECK THAT ALL SAFETY LOCKS ARE ENGAGED BEFORE PLACING A CHILD IN THE STROLLER.

USE THE HARNESS AT ALL TIMES.

NOT RECOMMENDED FOR A CHILD UNDER 6 MONTHS OLD.

WHEN NOT IN USE DISCONNECT SHOULDER STRAPS FROM THE WAIST STRAP AND/OR BUCKLE TO PREVENT STRANGULATION.

THE HARNESS CAN FORM LOOPS WHICH MAY BE A STRANGULATION HAZARD.

NEVER LEAVE A HARNESS CONNECTED WHEN NOT FITTED TO A CHILD IN THE STROLLER.

TO AVOID SERIOUS INJURY ALWAYS USE THE HARNESS PROVIDED TO SECURE THE CHILD. (ADJUST THE STRAPS TO SUIT THE SIZE OF YOUR CHILDS BODY)

IT IS UNSAFE TO USE ACCESSORIES OTHER THAN THOSE SUPPLIED BY LOVE N CARE.

CARE SHOULD BE TAKEN IF THE STROLLER IS TO BE USED ON STAIRS OR ESCALATORS.

THIS STROLLER SHOULD NOT BE USED NEAR AN OPEN FIRE OR AN EXPOSED FLAME.

CARE SHOULD BE TAKEN WHILST FOLDING AND UNFOLDING THE STROLLER TO PREVENT FINGERS BEING TRAPPED.

ENSURE YOUR CHILDS FINGERS, HANDS AND ALL OTHER BODY PARTS ARE CLEAR FROM ANY MOVING PARTS WHEN ADJUSTING THE SEAT OR HANDLE ON YOUR STROLLER.

USE THE TETHER STRAP TO PREVENT THE STROLLER FROM ROLLING AWAY.

DO NOT RUN WHILE USING THIS STROLLER.


THE UPRIGHT POSITIONS ARE NOT SUITABLE FOR USE WHEN CHILD IS LESS THAN 6 MONTHS OLD. THE LOWEST RECLINE POSITION SHOULD BE USED FOR CHILDREN UNDER 6 MONTHS.

MAXIMUM WEIGHT OF CHILD SHOULD NOT EXCEED FOR EACH SEAT: 17KG

MAXIMUM WEIGHT FOR BASKET: 4KGS

MAXIMUM WEIGHT FOR EACH CANOPY POCKET: 0.45KG

*PICTURES USED IN THIS MANUAL ARE FOR ILLUSTRATIVE PURPOSES ONLY. THE ACTUAL STROLLER MAY VARY IN DISPLAY.



PUSH-N-GO DUO

CARE AND MAINTENANCE

All Love N Care products have one year warranty from the date of purchase.

It is recommended to regularly inspect and maintain movement of locking devices and security of essential components.

To prolong the life of your stroller keep it clean and do not leave it in direct sunlight or in the boot of your car for extended periods of time.

Regularly check all parts for wear and tear. Lubricate if tight.

Removable fabric covers and trims may be cleaned using warm water with a household soap or mild detergent. Allow it to dry completely before re-use.

Non-removable fabrics and trims may be spot cleaned using a damp sponge with soap or mild detergent. Allow it to dry completely before folding or storing away.


Never clean with abrasive, ammonia based bleach based or spirit type cleaners.

If the wheels become damaged or worn discontinue use and replace.

FABRIC CARE

- HAND WASH ONLY
- DO NOT BLEACH
- DO NOT TUMBLE DRY
- DO NOT IRON
- DO NOT WRING
- DO NOT DRY CLEAN





PUSH-N-GO 

WARRANTY AGAINST DEFECTS

ALL LOVE N CARE PRODUCTS ARE GUARANTEED FOR TWELVE MONTHS FROM THE DATE OF PURCHASE.

OUR GOODS COME WITH GUARANTEES THAT CANNOT BE EXCLUDED UNDER THE AUSTRALIAN CONSUMER LAW. YOU ARE ENTITLED TO A REPLACEMENT OR REFUND FOR A MAJOR FAILURE AND FOR COMPENSATION FOR ANY OTHER REASONABLY FORSEEABLE LOSS OR DAMAGE. YOU ARE ALSO ENTITLED TO HAVE THE GOODS REPAIRED OR REPLACED IF THE GOODS FAIL TO BE OF ACCEPTABLE QUALITY AND THE FAILURE DOES NOT AMOUNT TO A MAJOR FAILURE.

THIS COVERS AGAINST FAULTS WHICH DEVELOP THROUGH FAULTY MATERIALS AND WORKMANSHIP. MISUSE, ACCIDENTAL DAMAGES, NORMAL WEAR AND TEAR OR NEGLECT ARE NOT COVERED.

IF A FAULT BECOMES APPARENT, PLEASE RETURN THE ITEM TO THE STORE OF PURCHASE WITH YOUR RECEIPT. YOU MUST INFORM THE STORE WHAT THE DEFECT IS. WE WILL THEN ARRANGE FOR ITS REPAIR OR IT WILL BE ASSESSED FOR REPLACEMENT AS EXPEDIENTLY AS POSSIBLE. THE BENEFITS OF THIS WARRANTY ARE IN ADDITION TO OTHER RIGHTS AND REMEDIES UNDER THE LAW IN RELATION TO THE GOODS AND SERVICES TO WHICH THIS WARRANTY RELATES.

IF YOU ARE UNABLE TO RETURN THE ITEM TO THE STORE OF PURCHASE, YOU CAN CONTACT LOVE N CARE ON FREECALL 1300732599. WE WILL THEN ORGANISE FOR EITHER SOMEBODY TO INSPECT THE ITEM OR ARRANGE FOR A COURIER TO PICK IT UP AND RETURN IT BACK TO YOU.

FOR MORE INFORMATION PLEASE CONTACT:

love n care[™]


LOVE N CARE PTY LTD

EMAIL: info@lovenecare.com.au

WEB: www.lovenecare.com.au

PHONE: 1300 732 599

FAX: 02 9774 4633



PUSH-N-GO DUO

Instructions - Unlocking frame and seat



Unclip the latch from the frame. (Located on the rear leg)



CLICK

Open the frame by pulling the frame in both directions until you hear a click which indicates the frame is fully opened and locked.



Push down on the stroller handle to make sure that the frame is locked.

Instructions - Assemble/Use and remove the front wheels



To **assemble the front wheels**, place each front wheel and insert it into each of the wheel mouldings.




Push the wheel and then press the release button on the wheel mouldings you should then hear a click. This should that the wheels are locked in. Pull on each wheel to ensure they are secured.



To **remove the front wheels**, press the buttons located on the bottom of the wheels mouldings then pull down on wheel to remove it. Repeat for both sides.



To **use the swivel wheels**, and lock the front wheels push the swivel lock upwards. To allow for the wheels to swivel push the swivel lock downwards. Always lock the swivel wheels when using the stroller on rough surfaces to minimise movement.



PUSH-N-GO DUO

Instructions - Use of brakes



To **lock the rear wheels**, press down on rear right red brake pedal to lock the brakes. Check that the brakes have been engaged by pushing the stroller forward.



To **release the brakes** push the rear brake pedal upwards.


⚠️ WARNING ⚠️

PUT ON ALL THE BRAKES WHENEVER YOU PARK THE STROLLER. ALWAYS APPLY THE BRAKES WHENEVER THE STROLLER IS STATIONARY.

Adjusting the footrest



To adjust the position of the footrest you can use the buttons located on the sides of the stroller to raise or lower the footrest to the desired position



PUSH-N-GO PUC

Instructions - Using and attaching the canopy



To **assemble the canopy**, insert the canopy mouldings into the frame mouldings. The Canopy Moulding should click into the the frame.




To adjust the canopy, you can open it by pulling it forward.



To lock the canopy push the arc on the sides of the canopy upwards.



To close the canopy just push it backwards.



PUSH-N-GO DUO

Instructions - Adjusting the backrest and using the tether strap




To lower the backrest, pull down on button on the backrest adjuster mechanism located at the top of the seats. With the button pressed pull the adjuster downwards and the backrest will also be lowered.

To raise the backrest, just pull the straps apart and push the seat forward.



A wrist tether strap is attached on the handle of the stroller. Slide your hand through the tether strap loop whenever you use the stroller. Only remove your hand from the tether strap loop when the brakes have been applied to the strollers wheels.





PUSH-N-GO DUO




Instructions - Using the Harness

⚠️ WARNING


USE THIS HARNESS AT ALL TIMES

⚠️ WARNING


WHEN NOT IN USE DISCONNECT SHOULDER STRAPS FROM THE WAIST STRAP AND/OR BUCKLE



Carefully place your child into the seat. Position its legs between the crotch strap. Place the shoulder strap (A) over the child's shoulders and place the waist strap (B) over its waist. Slide the shoulder strap buckle (A) along the rail on the top of the waist strap (B). Repeat for both sides.



With the shoulder strap (A) and waist strap (B) now connected, place them into the housing buckle (C). You should hear them click into place. Repeat for the other side. To release the harness, squeeze the center of the housing buckle. You can tighten or loosen the shoulder or waist straps by adjusting the sliders. Pull upwards to tighten or downwards to loosen.



PUSH-N-GO DUO

Instructions - Folding the stroller



To Fold the stroller, Kick or push up the 2 middle latches on the rear axel, then pull the side levers downwards




Push the stroller towards the front wheels.



Lock the frame together with the storage latch.



You can carry the stroller by using the handle on the side of the stroller.



Contact Us

Head Office:
Love N Care Pty Ltd.
297-299 Canterbury Rd, Revesby
NSW 2212 Australia
Contact No: 02 9774 4655
Fax: 02 9774 4633
Email: info@lovencare.com.au
Website: www.lovencare.com.au

Brisbane
7-9 Eileen Street
Underwood QLD 4119 Australia
Contact No: 07 3290 4217
Fax: 07 3209 5019

Western Australia
5 Modal Crescent
Canning Vale WA 6155 Australia
Contact No: 08 9455 4972
Fax: 08 9455 4728

let's be friends!

 <http://www.facebook.com/lovencare1>

 http://twitter.com/love_ncare



100 % AUSTRALIAN OWNED SINCE 1984

lovehncare[™]
lovencare.com.au