

■ GROUP INTERCALL (up to 6)

Step1. Turn on all devices.



- Press and hold (3sec.) all devices **PHONE/MUSIC** until LED on.

Step2. Setting up pairing No.1 and No.2 .



- Press and hold (3sec.) No.1's **CH2** and No.2's **CH1** until LED red flashes.
- Press No.1's **CH2** once.
- Until both devices slowly LED blue flashes, then pairing and calling succeed.

Step3. Setting up pairing No.2 and No.3 .



- Press and hold (3sec.) No.2's **CH2** and No.3's **CH1** until LED red flashes.
- Press No.2's **CH2** once.
- Until both devices LED blue slowly flashes, then pairing and calling succeed.

Step4. Setting up pairing devices in sequence.(up to 6)



- Press and hold (3sec.) No.3's **CH2** and No.4's **CH1** until LED red flashes.
- Press No.3's **CH2** once.
- Until both devices LED blue slowly flashes, then pairing and calling succeed.
- Setting up pairing devices in sequence, until all devices' pairing and calling succeed.

▲ NOTICE :

1. After initial pairing setting, devices will memorize pairing. For next use, just turn on the devices and click Channel button once and start to use.
2. Please insert phone jack to all devices before pairing, otherwise it may have echo during intercall. If it occurs, hang up and call out again.



Recommend application use:

- Long distance activity (over 500m) : 3 ppl
Such as kitesurf, surf, snow sports, etc. Recommend having max.3 people intercall.
- Short distance activity (100m ~ 500m) : 4~6 ppl
Such as wakeboard, sail, SUP, etc. Allow up to 6 people intercall.


■ RECORD VIDEO & VOICE BY GARMIN ACTION CAMERA (ultra 30)

Step1. Pair with Garmin.




- Enable Garmin's BLUETOOTH search mode.
- While OFF, press and hold (5sec.) **PHONE/MUSIC** until LED blue & red flashes.
- Select "BBT ADV" on Garmin screen.
- Pairing succeed.

Step2. Setting up pairing No.1, No.2, No.3 .



- Please follow the steps in "GROUP INTERCALL"

■ PAIR WITH SMART PHONE



- Enable smart phone's BLUETOOTH search mode.
- While OFF, press and hold (5sec.) **PHONE/MUSIC** until LED blue & red flashes.
- Select "BBT ADV" on phone screen.
- Pairing succeed.

▲ NOTICE :

After initial pairing setting, devices will memorize pairing. For next use, just turn on the devices and will automatically link. (make sure phone's BLUETOOTH is enable.)

■ LIVE COMMUNICATION

(1 smart phone + up to 3 Advance devices)


Step1. After pair with smart phone.

Turn on Adv No.2. & No.3. ★ Recommend to use at :




- Press and hold (5sec.) Adv.No.2 & No.3 **PHONE/MUSIC** until LED on.

Step2. Setting up pairing No.1 and No.2, No.3



- Press and hold (3sec.) No.1's **CH2** and No.2's **CH1** until LED red flashes.
- Press No.1's **CH2** once.
- Until both devices LED blue slowly flashes, then pairing and calling succeed.
- Press and hold (3sec.) No.2's **CH2** and No.3's **CH1** until LED red flashes.
- Press No.2's **CH2**.
- Until both devices LED blue slowly flashes, then pairing and calling succeed.



▲ NOTICE :

After pair with smart phone, can intercall with max. 3 Advance devices.

■ RECORD VIDEO & VOICE BY SMART PHONE



- After pair with smart phone, if you would like to take video and record the voice, must use app "Bb CAM".


■ RESET

While OFF, press and hold (3sec.) **PHONE/MUSIC** and **Vol+** until LED purple comes out.



■ UPDATE

- Download and install update tool and firmware from our website.
- Plug micro USB in PC. Press and hold(3sec.) **Vol+ & Vol-** until LED red & blue flashes.
- For more detail : bbtalkin.com/update



Scan the QR code to watch pairing video

There are more features will be released. Please follow our website to get the latest information and update Advance's firmware.



Bb TALKIN'

ADVANCE

A01R / A02R

USER GUIDE

Ver.0003

Thank you for choosing BbTALKIN ADVANCE.

This instruction manual will help you operate this system.
First, read this manual carefully and familiarize yourself
with functionalities before use.

www.bbtalkin.com

SPECS

| | |
|------------------------------|--------|
| Intercall talk time | 10 hr |
| Charge time | 2.5 hr |
| Weight | 62 g |
| Range | 1 mile |
| Water-proof | IPX 7 |
| *must in the waterproof case | |



CHARGING

- AC adaptor 5V± 5% min. 500mA
- Please make sure the device is completely dry before charge.
- Charging cable: Micro USB
- How to know battery status:
The second indicator LED after power ON.
Blue=100%-60%,
Purple=60%-40%
Red=battery low
- Battery Charge:
Red=Charging
Blue=Full charged

WARNING

- DO NOT modify or disassemble the device.
- The area you cannot use : in the airplane, near the person with medical devices or equipment such as pacemaker, etc.
- DO NOT expose this device to extreme temperature or humidity place.
- When Advance device gets damaged, stop using immediately.

DETAIL



LIMITED WARRANTY

This limited warranty covers defects in materials and workmanship in this product for twelve month (12) months for main device only.
The warranty obligations of BbTALKIN for this product are limited to the terms set forth below:
This limited warranty does not cover any damage, injury, USB part, deterioration or malfunction resulting from any alteration, misuse, accident, fire, flood, lightning, power surge, or other acts of nature. This limited warranty does not cover any damage, deterioration or malfunction resulting from the installation or removal of this product from any installation, any unauthorized tampering with this product, any repairs attempted by anyone unauthorized by BbTALKIN to make such repairs, or any other cause which does not relate directly to a defect in materials and/or workmanship of this product. This limited warranty does not cover cartons, equipment enclosures, cables or accessories used in conjunction with this product.
If this product is returned to BbTALKIN or the authorized dealer from which it was purchased or any other party authorized to repair BbTALKIN products, this product must be insured during shipment, with the insurance and shipping charges prepaid by you. If this product is returned uninsured, you assume all risks of loss or damage during shipment. BbTALKIN will not be responsible for any costs related to the removal or re-installation of this product from or into any installation. BbTALKIN will not be responsible for any costs related to any setting up this product, any adjustment of user controls or any programming required for a specific installation of this product.
It may damage your ears if using too long or too high volume sound. BbTALKIN will not be responsible for any damage to your ears or hearing caused by using the product for too long or too high volume sound.
Only the original purchaser of this product is covered under this limited warranty. This limited warranty is not transferable to subsequent purchasers or owners of this product.
How to Obtain a Remedy under this Limited Warranty
To obtain a remedy under this limited warranty, you must contact either the authorized BbTALKIN reseller from whom you purchased this product or the BbTALKIN office nearest you. For a list of authorized BbTALKIN resellers and/or BbTALKIN authorized service providers, please visit our web site at www.bbtalkin.com or contact the BbTALKIN dealer nearest you.
In order to pursue any remedy under this limited warranty, you must possess an original, dated receipt as proof of purchase from an authorized BbTALKIN reseller. If this product is returned under this limited warranty, a return authorization number, obtained from BbTALKIN, will be required. You may also be directed to an authorized reseller or a person authorized by BbTALKIN to repair the product. If it is decided that this product should be returned directly to BbTALKIN, this product should be properly packed, preferably in the original carton, for shipping. Cartons not bearing a return authorization number will be refused.
THE MAXIMUM LIABILITY OF BbTALKIN UNDER THIS LIMITED WARRANTY SHALL NOT EXCEED THE ACTUAL PURCHASE PRICE PAID FOR THE PRODUCT. TO THE MAXIMUM EXTENT PERMITTED BY LAW, BbTALKIN IS NOT RESPONSIBLE FOR DIRECT, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM ANY BREACH OF WARRANTY OR CONDITION, OR UNDER ANY OTHER LEGAL THEORY. Some countries, districts or states do not allow the exclusion or limitation of relief, special incidental, consequential or indirect damages, or the limitation of liability to specified amounts, so the above limitations or exclusions may not apply to you.



INTERCALL

After pair devices, click either one device **CH** once to call out / hang up the intercall.
Transmitter side: call out / hang up
Receiver side: automatically pick up / hang up

HANDSFREE

After pair with phone, incoming phone call :

- Click **PHONE/MUSIC** : Pick up / Hang up the phone call
- Click **PHONE/MUSIC** twice quickly : Decline a call / Redial


MUSIC PLAY

After pair with phone, play and pause music :

- Click **PHONE/MUSIC** once to play or pause music.
Forward and Backward :
- Press and hold 2sec. **Vol+** for forward music, **Vol-** for backward.

NOTICE


★ For long range uses such as kitesurfing coaching, still suggest 3 way intercall.



★ Do not pair 4 devices with phone.(Maximum 3 way+phone)



★ Distance will be 200m between each 1-2-3-4-5-6, totally more than 1km.



★ Require to keep the permutation(stay in line), the devices should always stay at the same position.



EX. The device 3 cannot go behind device 6, it should always stay between 2 and 4.



SIZE A5.

Compatible with Previous Models

1st DEVICE ↔ 2nd DEVICE → 3rd DEVICE

| | | | |
|----------|---------|---------|----------|
| | ADVANCE | ➡ | STANDARD |
| STANDARD | ➡ | ADVANCE | STANDARD |
| ADVANCE | ➡ | ADVANCE | STANDARD |
| | ADVANCE | ➡ | MASTER |
| ADVANCE | ➡ | MASTER | ADVANCE |
| ADVANCE | ➡ | MASTER | STANDARD |

Please follow below steps:

- STEP 1. Reset all devices.
- STEP 2. Pair 1st device and 2nd device.
- STEP 3. HANG UP the link between 1st and 2nd device. (IMPORTANT!)
- STEP 4. Pair 2nd and 3rd device.
- STEP 5. Call out 1st device again to have 3 way intercall.

▲ NOTICE :

- 1.Must call out from 2nd device.
- 2.If pairing doesn't succeed (such as device shut down, no voice, button no response, etc.), please do above pairing steps again.
- 3.After set up pairing, no need to pair again for next use.
- 4.Except the above list combinations, we can not guarantee other combinations can work properly.
- 5.We strongly suggest to pair with same model.

SIZE A5.