

SECURA TRACK

The **Low Cost** inventory control solution for manned storerooms, service vehicles and POU free issue products

SECURATRACK KIT INCLUDES:

- SecuraTrack Cube
- Monitor – with 10' extended cable
- Barcode Scanner – with 6' extended cable
- Ethernet cord – 15' extended
- AC Power Cord – 15' extended
- 4 hour back up power
- Mobile operation without power and internet
- Cloud synchronization whenever connected to Internet
- Instructional Graphic Strip Decals
- Manual Keys
- Laminated On-demand entry sheet
- Optional: Universal Badge Reader
- Optional: Camera Surveillance System
- Optional: Service Vehicle kit (take SecuraTrack on the road!)

SecuraTrack uses the same scanning technology and software system as our vending machines, but has almost unlimited capacity and mobility.



Dimensions: 13" x 13" x 13" Weight: 45 lbs.



SECURA



TRACK

TWO OPTIONS TO AUTHENTICATE USERS

The **first step** for any transaction is to authenticate the user. Users can be authenticated by either:

Scanning the user's Parts Crib ID barcode with the barcode scanner. (The Parts Crib ID barcodes are printed from the Configuration – Users page in the software.)

OR

Use optional Universal Badge Reader.



COMPLETE AN ISSUE TRANSACTION

1. Authenticate the user.
2. Scan the Product ID barcode for the item being issued.

COMPLETE A RETURN TRANSACTION

1. Authenticate the user.
2. Scan the "Return" barcode.
3. Scan the Product ID barcode for the item being returned.

CYCLE COUNT

Cycle Counts are easier when SecuraTrack is unplugged and mobile.

1. Only certain users approved to perform this, already preloaded.
2. Scan the "Cycle Count" barcode.
3. Scan the Product ID barcode for the item being counted.

The monitor will display "Cycle Count" information.

4. Use barcodes for numerals on the "On Demand" sheet to enter the quantity counted.
5. If counting additional items, simply scan the next Product's barcode.