



Lynx® Smart Satellite

Board Exchange Details

- Core charge will be invoiced with each board shipped.
- Pre-paid UPS return label will be included with shipment of replacement board to ship failed board back.
- Core charge will be refunded upon receipt of failed board.
- **If failed board is not received within 60 days, core charge will not be refunded.**

Shipping Details

After receipt of replacement board, package failed board and ship back to us using provided UPS return label to:

Turf Equipment and Supply Co, Inc.
8015 Dorsey Run Road
Attn: BEP CORE RETURN
Jessup, MD 20794

Control and Distribution Boards



R118-6363 Timing Mechanism



R118-3045 Distribution Board




Distribution
R118-3128 Expansion Board

Surge Boards




R118-1524 Pump/Common Surge



R118-3047 Output Surge

Output Boards



R118-6370 Relay Output Board

Pump/Common Boards



R118-6369 Pump/Common Relay



Pump/Common
R118-6034 Terminal Board

Modems/Radio Boards



R118-3339 Radio Interface



R118-3442 Radio Module

*Radio settings are programmable in timing mechanism menu.



R118-3705 Wireline Modem

*** Contact our Customer Service team or your Territory Manager for current unit pricing and core charges. ***

Follow us on:



www.turf-equipment.com | 800-827-3711



Network VP® Controller

Board Exchange Details

- Core charge will be invoiced with each board shipped.
- Pre-paid UPS return label will be included with shipment of replacement board to ship failed board back.
- Core charge will be refunded upon receipt of failed board.
- **If failed board is not received within 60 days, core charge will not be refunded.**

Shipping Details

After receipt of replacement board, package failed board and ship back to us using provided UPS return label to:

Turf Equipment and Supply Co, Inc.
8015 Dorsey Run Road
Attn: BEP CORE RETURN
Jessup, MD 20794

Control and Distribution Boards



R102-3497-4.0 **Timing Mechanism**



R102-2782 **Distribution Board**

*May ship as LEAD-FREE part number R102-8576



R118-2737 **Vertical Distribution Board**



R102-9124 **LTC+ to VP Upgrade Distribution Board**



R89-9894 **24-Volt Bus Bar**

*May ship as LEAD-FREE part number R102-8392



R89-9896 **Grounding Bus Bar**

*May ship as LEAD-FREE part number R102-8393

Surge Boards




R89-8589 **Pump/Common Surge**



R89-9804 **16 Station Surge Board**

Output Boards



R102-2549 **8 Station Output Module**

*May ship as LEAD-FREE part number R102-8242

Pump/Common Boards



R102-3015 **Pump/Common Board**

*May ship as LEAD-FREE part number R102-8577

Modems/Radio Boards



* R102-0104 **Standard Modem**

*May ship as LEAD-FREE part number R102-8568



* R102-0106 **Universal Modem (Radio)**

*May ship as LEAD-FREE part number R102-8570



R102-3125 **Radio Power Supply**

*May ship as LEAD-FREE part number R102-8277



R363-4638 **Maxon Radio Transceiver**

*Customer frequency needed before this can be shipped.

* Recommended modems for this controller

*** Contact our Customer Service team or your Territory Manager for current unit pricing and core charges. ***

Follow us on:



www.turf-equipment.com | 800-827-3711



Network LTC® Plus Controller

Board Exchange Details

- Core charge will be invoiced with each board shipped.
- Pre-paid UPS return label will be included with shipment of replacement board to ship failed board back.
- Core charge will be refunded upon receipt of failed board.
- **If failed board is not received within 60 days, core charge will not be refunded.**

Shipping Details

After receipt of replacement board, package failed board and ship back to us using provided UPS return label to:

Turf Equipment and Supply Co, Inc.
8015 Dorsey Run Road
Attn: BEP CORE RETURN
Jessup, MD 20794

Control and Distribution Boards



R102-0238 Timing Mechanism



R102-0612 Distribution Board

*May ship as LEAD-FREE part number R102-8078

Surge Boards



R89-8589 Pump/Common Surge

*May ship as LEAD-FREE part number R102-8086



R89-8521 16 Station Surge Board

Output Board



R102-0681 8 Station Output Module

Pump/Common Board



R102-0682 Pump/Common Board

*May ship as LEAD-FREE part number R102-8082

Modems/Radio Boards



R35-8646 Standard Modem



R89-7519 Standard Modem (Old Version)

*Board availability limited, recommended only if new



*** R102-0104 Standard Modem (New Version)**

*May ship as LEAD-FREE part number R102-8568



*** R102-0106 Universal Modem (Radio)**

*May ship as LEAD-FREE part number R102-8570



R363-4638 Maxon Radio Transceiver

*Customer frequency needed before this can be shipped.

* Recommended modems for this controller

Upgrade your controllers to LTC Pro or VP



118-4838 LTC Pro Upgrade Kit

Buy 2, Get 1 Free

** Ends 10/02/19 **



118-0038 VP Upgrade Kit

Buy 2, Get 1 Free

** Ends 10/02/19 **

*** Contact our Customer Service team or your Territory Manager for current unit pricing and core charges. ***

Follow us on:



www.turf-equipment.com | 800-827-3711



Network LTC® 2.0 Controller

Board Exchange Details

- Core charge will be invoiced with each board shipped.
- Pre-paid UPS return label will be included with shipment of replacement board to ship failed board back.
- Core charge will be refunded upon receipt of failed board.
- **If failed board is not received within 60 days, core charge will not be refunded.**

Shipping Details

After receipt of replacement board, package failed board and ship back to us using provided UPS return label to:

Turf Equipment and Supply Co, Inc.
8015 Dorsey Run Road
Attn: BEP CORE RETURN
Jessup, MD 20794

Control and Distribution Boards



R89-7169 Timing Mechanism



R89-6977 Back Plane

Surge Board



R91-1307 Communication
Surge Board

Output Board



R89-7170 4 Station Output Module

Pump/Common Board



R89-7171 Pump/Common Board

Modems/Radio Boards



R35-8646 Standard Modem



* R89-7519 Standard Modem
(Old Version)

*Board availability limited, recommended only if new version does not work.



R102-0104 Standard Modem
(New Version)

*May ship as LEAD-FREE part number R102-8568

* Recommended modems for this controller

*** Contact our Customer Service team or your Territory Manager for current unit pricing and core charges. ***

Follow us on:



www.turf-equipment.com | 800-827-3711



Network LTC® 1.1 Controller

Board Exchange Details

- Core charge will be invoiced with each board shipped.
- Pre-paid UPS return label will be included with shipment of replacement board to ship failed board back.
- Core charge will be refunded upon receipt of failed board.
- **If failed board is not received within 60 days, core charge will not be refunded.**

Shipping Details

After receipt of replacement board, package failed board and ship back to us using provided UPS return label to:

Turf Equipment and Supply Co, Inc.
8015 Dorsey Run Road
Attn: BEP CORE RETURN
Jessup, MD 20794

Control and Distribution Boards



R91-0537 **Timing Mechanism
with Terminal Block**

Modems/Radio Board

R91-0777 **Standard Modem**

Surge Boards



R91-1303 **8 Station Surge Board**



R91-1305 **Neutral Surge Board**



R91-1307 **Communication
Surge Board**

*** Contact our Customer Service team or your Territory Manager for current unit pricing and core charges. ***

Follow us on:



www.turf-equipment.com | 800-827-3711



Network 8000® Controller

Board Exchange Details

- Core charge will be invoiced with each board shipped.
- Pre-paid UPS return label will be included with shipment of replacement board to ship failed board back.
- Core charge will be refunded upon receipt of failed board.
- **If failed board is not received within 60 days, core charge will not be refunded.**

Shipping Details


After receipt of replacement board, package failed board and ship back to us using provided UPS return label to:

Turf Equipment and Supply Co, Inc.
8015 Dorsey Run Road
Attn: BEP CORE RETURN
Jessup, MD 20794

Control and Distribution Boards



R91-1280 Timing Mechanism



R35-6166 Power Supply

Pump/Common Boards



R35-6326 Pump Module



R35-8502 Valve Board

Surge Board



R35-7899 Surge Board

Output Board



R89-8100 4 Station Triac Board

Modems/Radio Boards



* R35-8646 Standard Modem



R89-7519 Standard Modem
(Old Version)

*Board availability limited, recommended only if new version does not work.



* R102-0104 Standard Modem
(New Version)

*May ship as LEAD-FREE part number R102-8568



* R102-0106 Universal Modem
(Radio)

*May ship as LEAD-FREE part number R102-8570

* Recommended modems for this controller

*** Contact our Customer Service team or your Territory Manager for current unit pricing and core charges. ***

Follow us on:



www.turf-equipment.com | 800-827-3711



OSMAC® G3 Controller
(2019 version)

Board Exchange Details

- Core charge will be invoiced with each board shipped.
- Pre-paid UPS return label will be included with shipment of replacement board to ship failed board back.
- Core charge will be refunded upon receipt of failed board.
- **If failed board is not received within 60 days, core charge will not be refunded.**

Shipping Details

After receipt of replacement board, package failed board and ship back to us using provided UPS return label to:

Turf Equipment and Supply Co, Inc.
8015 Dorsey Run Road
Attn: BEP CORE RETURN
Jessup, MD 20794

Control and Distribution Boards



R118-2986 **Timing Mechanism**

*Radio frequency and settings are programmable in timing



R118-3045 **Distribution Board**



R118-3128 **Distribution
Expansion Board**

Surge Boards



R118-1524 **Pump/Common Surge**



R118-3047 **Output Surge**

Output Board



R118-6370 **Relay Output Board**

Pump/Common Boards



R118-6369 **Pump/Common Relay**



R118-6034 **Pump/Common
Terminal Board**

*** Contact our Customer Service team or your Territory Manager for current unit pricing and core charges. ***

Follow us on:



www.turf-equipment.com | 800-827-3711



OSMAC® G3 Controller
(pre-2019 version)

Board Exchange Details

- Core charge will be invoiced with each board shipped.
- Pre-paid UPS return label will be included with shipment of replacement board to ship failed board back.
- Core charge will be refunded upon receipt of failed board.
- **If failed board is not received within 60 days, core charge will not be refunded.**

Shipping Details

After receipt of replacement board, package failed board and ship back to us using provided UPS return label to:

Turf Equipment and Supply Co, Inc.
8015 Dorsey Run Road
Attn: BEP CORE RETURN
Jessup, MD 20794

Control and Distribution Boards



R118-2986 Timing Mechanism

*Radio frequency and settings are programmable in timing



R102-0318 Distribution Board

*May ship as LEAD-FREE part number R102-8084



R89-9894 24-Volt Bus Bar

*May ship as LEAD-FREE part number R102-8392



R89-9896 Grounding Bus Bar

*May ship as LEAD-FREE part number R102-8393

Output Board



R102-2549 8 Station Output Module

*May ship as LEAD-FREE part number R102-8242

Pump/Common Board



R102-0320 Pump/Common Board

Surge Board



R89-9804 16 Station Surge Board

*** Contact our Customer Service team or your Territory Manager for current unit pricing and core charges. ***

Follow us on:



www.turf-equipment.com | 800-827-3711



E-OSMAC® Controller

Board Exchange Details

- Core charge will be invoiced with each board shipped.
- Pre-paid UPS return label will be included with shipment of replacement board to ship failed board back.
- Core charge will be refunded upon receipt of failed board.
- **If failed board is not received within 60 days, core charge will not be refunded.**

Shipping Details

After receipt of replacement board, package failed board and ship back to us using provided UPS return label to:

Turf Equipment and Supply Co, Inc.
8015 Dorsey Run Road
Attn: BEP CORE RETURN
Jessup, MD 20794

Control and Distribution Boards



R102-0187 Narrowband Receiver Card

*Customer frequency needed before this can be shipped.



R89-9449-BS Wideband Receiver Card

*Must be used with Potsag chip P/N 102-1758



R102-0318 Distribution Board

*May ship as LEAD-FREE part number R102-8084



R89-9894 24-Volt Bus Bar


*May ship as LEAD-FREE part number R102-8392



R89-9896 Grounding Bus Bar

*May ship as LEAD-FREE part number R102-8393

Output Board



R102-2549 8 Station Output Module

*May ship as LEAD-FREE part number R102-8242

Pump/Common Board



R102-0320 Pump/Common Board

Surge Boards



R89-8589 Pump/Common Surge



R89-9804 16 Station Surge Board

Upgrade your controllers to Osmac G3



118-2987 Osmac G3 Upgrade Kit

Buy 3, Get 1 Free

** Ends 10/02/19 **

*** Contact our Customer Service team or your Territory Manager for current unit pricing and core charges. ***

Follow us on:



www.turf-equipment.com | 800-827-3711



RDR OSMAC® Controller

Board Exchange Details

- Core charge will be invoiced with each board shipped.
- Pre-paid UPS return label will be included with shipment of replacement board to ship failed board back.
- Core charge will be refunded upon receipt of failed board.
- **If failed board is not received within 60 days, core charge will not be refunded.**

Shipping Details

After receipt of replacement board, package failed board and ship back to us using provided UPS return label to:

Turf Equipment and Supply Co, Inc.
8015 Dorsey Run Road
Attn: BEP CORE RETURN
Jessup, MD 20794

Control and Distribution Boards



RNLN3485

Narrowband Receiver Card

*Must be used with Potsag chip
P/N 102-1758



R102-2012

Narrowband Upgrade Card

*Customer frequency needed
before this can be shipped.

Surge Boards



R91-1303 8 Station Surge Board



R91-1305 Neutral Surge Board

Output Board



RNLN3491A 8 Station Triac Board

*** Contact our Customer Service team or your Territory Manager for current unit pricing and core charges. ***

Follow us on:



www.turf-equipment.com | 800-827-3711



Lynx® Smart Hub

Board Exchange Details

- Core charge will be invoiced with each board shipped.
- Pre-paid UPS return label will be included with shipment of replacement board to ship failed board back.
- Core charge will be refunded upon receipt of failed board.
- **If failed board is not received within 60 days, core charge will not be refunded.**

Shipping Details

After receipt of replacement board, package failed board and ship back to us using provided UPS return label to:

Turf Equipment and Supply Co, Inc.
8015 Dorsey Run Road
Attn: BEP CORE RETURN
Jessup, MD 20794

Control and Distribution Boards



R118-4728 **Timing Mechanism**



R118-0582 **2-Wire Motherboard**

*Must be used with daughterboard P/N R118-0584



R118-0584 **2-Wire Daughterboard**

*Must be used with motherboard P/N R118-0582

Surge Boards



R102-8086 **Pump/Common Surge**



R118-7187 **Output Surge**

Modems/Radio Boards



R118-3101SK **Radio Interface**



R118-3442 **Radio Module**

*Radio settings are programmable in timing mechanism menu.



R118-3705 **Wireline Modem**

*** Contact our Customer Service team or your Territory Manager for current unit pricing and core charges. ***

Follow us on:



www.turf-equipment.com | 800-827-3711



GDC 2-wire Gateway

Board Exchange Details

- Core charge will be invoiced with each board shipped.
- Pre-paid UPS return label will be included with shipment of replacement board to ship failed board back.
- Core charge will be refunded upon receipt of failed board.
- **If failed board is not received within 60 days, core charge will not be refunded.**

Shipping Details

After receipt of replacement board, package failed board and ship back to us using provided UPS return label to:

Turf Equipment and Supply Co, Inc.
8015 Dorsey Run Road
Attn: BEP CORE RETURN
Jessup, MD 20794

Control and Distribution Boards



R102-5918 **Timing Mechanism**



R102-7696 **2-Wire Motherboard**

*Must be used with daughterboard P/N R102-7693



R102-7693 **2-Wire Daughterboard**

*Must be used with motherboard P/N R102-7696



R118-0582 **2-Wire Motherboard**

*Must be used with daughterboard P/N R118-0584



R118-0584 **2-Wire Daughterboard**

*Must be used with motherboard P/N R118-0582

Modems/Radio Boards



R118-3101SK **Radio Interface**



R118-3442 **Radio Module**

*Radio frequency and settings must be pre-programmed prior to use

*** Contact our Customer Service team or your Territory Manager for current unit pricing and core charges. ***

Follow us on:



www.turf-equipment.com | 800-827-3711