Dashr

ANDROID

Pro-Agility

Finish
5 yards
5 yards
Start

Dash

Start
Finish

Lap

Lap Start

Dash with Split

Start
10yd Split
40yd Finish

Flying 40

Start
Laser Start
10yd Split
40yd Finish
5 yd
10 yd
30 yd

| Test	Lasers	Reflectors	Mini Tripod	Regular Tripod
Pro-Agility	1	1	0	2
Dash	2	2	2	2
Lap	1	1	0	2
Dash w/ Split	3	3	2	4
Flying 40	3	3	0	6

Mobile App

Introduction Screen

Selection of an event will send you directly to the laser connection page. Opening screen allows you to quickly select the desired event.

Laser Select Screen

Dash Connect

Start Laser

Stop Laser

START TIMING

In the laser selection page, add a laser by turn on the desired laser then selecting the lightening bolt. The laser will automatically select.
Note: Phone must be on for a couple minutes for Bluetooth to boot up.

Settings Screen

Settings

Configuration
QuickRun

Add-ons
DrillStack
advertise timing data after each run via BLE

In settings, you can enable QuickRun which allows the system to automatically reset and set when the next athlete steps up. Here you can also add a Dashr Code to transmit timing results to various other devices and programs.

Event Screen

Dash
Current Athlete: none
Start Laser
Stop Laser

GO!

QuickRun ✓

00.00   00.00   00.00

Testing   History   Settings

Laser indicators change to color when connected. Green indicates an unbroken laser where red indicates broken.

Numbers turn blue while event is active. Once the laser has been crossed, the time will appear.

Shows QuickRun is activated.

Event Screen

Pro-Agility

1.56
00.00

SET   SAVE   RESET

1.73   2.09   2.34
3.65   4.19   4.06

Testing   History   Settings

The "Ready" and "Reset" buttons are used to run the tests. The previous three times are displayed under these buttons.

Dashr