EcoCare

ECOCARE EDUSERIES · WATER TREATMENT EDITION · 12 NOVEMBER 2026

Inside a Four-Year RO Membrane Autopsy — Scaling, Cleaning and the Ageing You Can't Reverse

A technical bulletin for utility engineers, plant managers and QA heads who run reverse-osmosis plants — packaged drinking water, dairy, beverage and boiler-feed pre-treatment.

Background: we replace membranes, but rarely learn from them

Most Indian plants running reverse osmosis — packaged drinking water lines, dairies polishing permeate and condensate, beverage plants, boiler-feed pre-treatment — manage membranes on two numbers: feed pressure and permeate TDS. When the pressure creeps up, we clean. When the TDS complaint arrives, we replace. The old elements go to scrap, and the plant never finds out what actually happened inside the module.

A new study in the journal Desalination (Volume 638, issue dated 15 November 2026) does that homework in unusual detail. Researchers at the University of Southern California autopsied spiral-wound RO modules pulled from the Orange County Groundwater Replenishment System — the world's largest potable-reuse plant — after one, two and four years of continuous service, and compared them against pristine flat-sheet membranes and unused membranes that had already been rolled into modules. They paired electron microscopy, EDS elemental mapping and atomic-force microscopy with the plant's own SCADA records of pressure, salt rejection and every clean-in-place (CIP) event. The result is one of the clearest pictures yet of how a working membrane actually ages.

What the autopsy found

Four findings stand out for plant operators:


- Damage begins before the first litre is filtered. Simply rolling the flat sheet into a spiral-wound module leaves spacer imprints and dents; inside those imprinted regions, the void spaces of the salt-rejecting polyamide layer were about 67% smaller — localised densification invisible to any routine test.
- Compaction is front-loaded. Total membrane thickness fell about 18% in the first year, 20% by year two and 23% by year four. Most of the physical compression your membranes will ever suffer happens in year one.
- The surface ages unevenly — and scale stays behind. Autopsied coupons showed residual silica scale, particle clusters and surface cracks that cleaning had not removed. Mean crack width grew from about 0.6 µm after one year to 4.9 µm after four — roughly eight times wider — and surface roughness nearly doubled.

- The number that matters: salt rejection fell from above 99% to below 98% over four years — salt passage roughly doubled — and the SCADA record showed salt passage stepping up after CIP events. Cleaning recovered flow, but it did not recover rejection.

That last point deserves a plain-language translation: CIP has two different jobs, and it only reliably does one of them. It can strip the foulant layer and restore permeate flow and pressure drop. It cannot un-compact a densified polyamide layer, close a crack, or dissolve silica that has already polymerised on the surface — no routine cleaner does, within the pH and temperature limits membrane manufacturers allow.

Four years inside a working RO module — field autopsy data

Source: Ding & Childress, Desalination 638 (2026) 120605 — modules autopsied after 1, 2 and 4 years of potable-reuse service



What the supporting literature adds

Two further references complete the operational picture.

First, prevention chemistry is dose-sensitive. A February 2026 study in ACS Omega by researchers at King Fahd University of Petroleum & Minerals synthesised a polymeric antiscalant carrying aspartic-acid and maleic-acid chelating motifs. At 2.5 ppm it held calcium sulphate scaling at close to 100% inhibition for an induction period of about 820 minutes; at 0.5–1 ppm and 40 °C, the induction period collapsed to just 40–60 minutes. The lesson is not about one polymer — it is that antiscalant dose and chemistry decide how long your system stays ahead of the first crystal, and that underdosing fails quietly, hours before any pressure gauge notices.

Second, raw instrument readings mislead. Feed temperature, feed TDS and recovery all move daily, and each one moves permeate flow and salt passage on its own. ASTM D4516, the standard practice for normalising RO performance data, exists precisely so that operators can separate genuine fouling and ageing from seasonal physics. A plant that trends only raw flow and raw TDS will clean too late, or clean the wrong problem.

EcoCare's own analysis: what membrane ageing costs a 10 KL/hr plant

EcoCare's own analysis — The following worked example is EcoCare's own analysis, not part of the cited studies. Figures marked as assumptions should be replaced with your plant's actual data.

Known data and assumptions: a packaged drinking-water plant producing 10 KL/hr of permeate at 70% recovery, running 20 hr/day for 330 days a year (66,000 KL permeate/year); a

membrane bank of 12 × 8-inch elements at an assumed ₹25,000 per element (₹3.0 lakh per bank); antiscalant dosed at 3 ppm on feed, at a reference price of ₹270/kg (to be confirmed at the time of quotation).

Step 1 — Feed flow: 10 KL/hr ÷ 0.70 recovery = 14.3 KL/hr of feed.

Step 2 — Antiscalant consumption: 14.3 KL/hr × 3 g/KL = 43 g/hr ≈ 0.86 kg/day ≈ 283 kg/year. At ₹270/kg, that is about ₹76,400/year, or ₹1.16 per KL of permeate.

Step 3 — Membrane amortisation: at a 3-year life, the ₹3.0 lakh bank costs ₹1.0 lakh/year (₹1.52/KL). Stretch the same bank to 5 years and the cost falls to ₹60,000/year (₹0.91/KL) — a saving of about ₹40,000/year for one small bank, before counting cartridge filters, downtime and labour.

Step 4 — The quality margin, which is usually the real constraint: when rejection slides from 99% to 98%, salt passage doubles, and so does the permeate TDS for the same feed. A packaged-water plant blending close to its specification limit, or a boiler house holding tight feed-water conductivity, is forced to replace membranes on rejection, not pressure. Roughly ₹1.2/KL of prevention chemistry is therefore protecting an asset stream worth ₹1.5/KL — and the product quality on top of it.

A checklist you can run this week

1. Normalise before you judge. Set up weekly normalised permeate flow, normalised salt passage and per-stage differential pressure per ASTM D4516 — trend these, not raw gauge readings.
2. Fix CIP triggers to data, not the calendar: clean at a 10–15% drop in normalised flow or a 10–15% rise in differential pressure, whichever comes first.
3. Track salt passage after every CIP. A step-up in normalised salt passage immediately after cleaning indicates ageing or membrane damage, not fouling — no stronger chemical will bring it back.
4. Verify the antiscalant dose at the pump with a drawdown test this week. A 3 ppm programme that is actually running at 1 ppm gives minutes of protection, not hours.
5. Match the antiscalant to a current feed analysis — including reactive silica, not just hardness and TDS — and keep reject-side silica within the product's rated limit; if you cannot, reduce recovery.
6. Check pre-treatment guards: SDI below 3 at the membrane inlet, and cartridge filter ΔP within limits.
7. Hold CIP discipline: low-pH clean first for mineral scale, then high-pH for organics and biofilm; stay within the membrane maker's pH and temperature limits; rinse to a stable conductivity endpoint; record every CIP with before/after normalised data.
8. When you do replace elements, keep one for autopsy — photograph the lead and tail elements, cut one open, and record what you find. It is the cheapest R&D your water plant will ever do.

Where EcoCare fits

EcoCare Technologies manufactures RO antiscalants, acid and alkaline membrane cleaners and non-oxidising RO biocides at its Noida plant, and supports them with the unglamorous work this article describes: feed-water analysis, dosing audits with drawdown verification,

normalised-data reviews and CIP procedure trials on site. Correctly selected and verified dosing programmes of this kind can help extend the interval between cleanings and protect rejection life — subject to validation on your plant's own feed water and operating data. For a review of your RO normalised data or a dosing audit, write to ecocare@ecocaretech.com.

Sources

1. Ding, W. & Childress, A.E., "Characterization of reverse osmosis membranes over their lifespan: Pre-operational defects, surface scaling, and cross-sectional morphological changes", Desalination, Vol. 638, 120605 (15 November 2026). https://www.sciencedirect.com/science/article/pii/S0011916426007617

2. Ali, S.A. et al., "Development of a Polymeric Antiscalant Having Chelating Motifs of Aspartic and Maleic Acid for Inhibiting Scale Formation on Reverse Osmosis Membranes", ACS Omega 11(7), 12029–12037 (24 February 2026). https://pubs.acs.org/doi/10.1021/acsomega.5c11194

3. ASTM D4516, Standard Practice for Standardizing Reverse Osmosis Performance Data, ASTM International. https://www.astm.org/d4516-19a.html

---

Hygiene · Safety · Trust — © 2026 EcoCare Technologies Pvt. Ltd. This bulletin is for general technical information; programme selection and dosing require validation on your plant's own feed water and operating data.