





Assembly Instructions

Jonesport Bed Rails

- A.** From the hardware and instructions originally included with the crib, locate two 1-1/8" Allen Bolts (P), and two Cap Nuts (Q). Thread them through the holes in the headboard as shown, and tighten securely using the allen wrench included with the crib hardware.
- B.** Insert the metal tab on the bed rail into the slot on the headboard post, with the hooks facing down and the slat supports toward the inside. Drop the hooks on to the internal pins, making sure the rail is securely seated. Repeat for the other rail.
- C.** Insert the bed rail hooks into the footboard slots. Make sure both rails are secure and stable.
- D.** If you want to use the slats, evenly space them along the rails, and if desired, secure them to the rails using the wood screws.



WESTWOOD DESIGN

635 N. Billy Mitchell Rd., Ste. B
 Salt Lake City, UT 84116
 Phone: 1-908-719-4707
 support@westwoodbaby.com

August 1, 2011