

# OPTIMA·OPTIMA *XM*

## CUSTOMER INSTRUCTIONS

### TO SET THE SYSTEM (turn on)

The Day indicator should be showing. Enter your code number. Check that the system is clear (none of the zone indicators are showing). If clear, the sounder will produce a bleep tone and you may now leave by the approved route. The system will Set at the end of the exit time and the tone will stop. If the system is not clear, the sounder will produce a broken tone and the zone fault will be displayed. Either re-enter your code to turn off and investigate, or omit the faulty zone from the system.

### TO UNSET THE SYSTEM (turn off)

Enter your code, if the system is clear (no alarm has been activated) the system will return to Day. If the system has been activated, then entering the code will turn off the alarm and cause the condition to be displayed. Press RESET to clear the indication and return to Day.

### TO OMIT A ZONE

Starting from the Day mode, enter your code and the exit tone will start. Press the OMIT button and the exit tone changes to an omit tone. Now enter the zones you wish to omit e.g. pressing 2 then 4 will remove zones 2 and 4 from the system. The zone 2 and 4 indicators will now be displayed.

If you make a mistake, press 0 to cancel and then enter the zones required to be omitted. When the selection is correct press SET. The system will now return to exit mode and the exit tone will continue.

### QUICK SET

During exit time (after entering your code) the system may be Set quickly by pressing SET. This removes the time normally allowed for exit and would be used if you are not leaving the premises. If you omit zones and require quick Set, press SET twice.

### POWER INDICATOR

A red Power indicator should be showing on the control panel at all times. If this indicator goes out, the mains supply has failed or been disconnected. If in doubt call the engineer for assistance.

### FAULTS/PROBLEMS

It is important to have your alarm system checked and tested regularly to ensure correct operation. It is also advisable to have a maintenance contract or agreement with the alarm installation company.

If any faults occur, or any fault indicators remain on the display and cannot be cleared, call the engineer.

Fill in the details below, to help keep a record of your alarm system.

ALARM COMPANY NAME .....

ADDRESS .....

TEL. NO. DAY..... TEL. NO. NIGHT .....

DATE OF INSTALLATION..... ACCOUNT NO. ....

ZONE	AREA PROTECTED
1	
2	
3	
4	

## CUSTOMER PROGRAMMING

Customer code change, alarm memory recall and alarm tests are all available from the customer programme. With the Day indicator showing, press the following buttons in the correct sequence.

### CODE CHANGE

Press **PROG** button All indicators will show

Enter your code

?	?	?	?
---	---	---	---

DAY and TAMPER indicators show

Press **8** Four Zone indicators show

Now enter your new code (4 digits)

--	--	--	--

The system will beep twice and DAY and TAMPER indicators show again.

Press **RESET** to return to Day The new code is now in the memory

### ALARM MEMORY RECALL

Press **PROG** button All indicators will show

Enter your code

?	?	?	?
---	---	---	---

DAY and TAMPER indicators show

Press **MEM** button The last alarm will now be displayed for 5 seconds. The system will beep and DAY and TAMPER indicators will show again.

Press **RESET** to return to Day

### ALARM TESTS

Press **PROG** button All indicators will show

Enter your code

?	?	?	?
---	---	---	---

DAY and TAMPER indicators show

Press **0** DAY, TAMPER and ATTACK indicators show

The system is now in the test routine

Press **2** To test the strobe

Press **0** to stop

Press **3** To test outside bell/sounder

Press **0** to stop

Press **4** To test low volume inside sounder

Press **0** to stop

Press **2** **4** To test high volume inside sounder

Press **0** to stop

Press **5** To enter walk test. The sounder will now beep each time a zone is opened.

Press **0** to stop

Press **RESET** **RESET** to return to Day