

WESTWOOD DESIGN



Assembly Instructions Jonesport Convertible Crib





WARNING

FAILURE TO FOLLOW THESE WARNINGS AND ASSEMBLY INSTRUCTIONS COULD RESULT IN SERIOUS INJURY OR DEATH.

- READ ALL INSTRUCTIONS BEFORE ASSEMBLING CRIB. **KEEP INSTRUCTIONS FOR FUTURE USE.**
- TO REDUCE THE RISK OF SUDDEN INFANT DEATH SYNDROME (SIDS), PEDIATRICIANS RECOMMEND HEALTHY INFANTS BE PLACED ON THEIR BACKS TO SLEEP, UNLESS OTHERWISE ADVISED BY YOUR PHYSICIAN.
- PREVENT BURNS. KEEP CRIB AWAY FROM OPEN FIRES AND OTHER HEAT SOURCES.
- ANY MATTRESS USED IN THIS CRIB MUST BE AT LEAST 27-1/4 IN. (69 CM.) BY 51-5/8 IN. (131 CM.), WITH A THICKNESS NOT EXCEEDING 6 IN. (15 CM.). THE DIMENSIONS OF THE MATTRESS SHOULD BE TAKEN FROM SEAM TO SEAM.
- **DO NOT** USE A WATER MATTRESS WITH THIS CRIB.
- NEVER USE PLASTIC SHIPPING BAGS OR OTHER PLASTIC FILM AS A MATTRESS COVER BECAUSE THEY CAN CAUSE SUFFOCATION.
- IF REFINISHING, USE A NON-TOXIC FINISH SPECIFIED FOR CHILDREN'S PRODUCTS.
- FOLLOW WARNINGS ON ALL PRODUCTS IN CRIB.

SUFFOCATION HAZARD:

- INFANTS CAN SUFFOCATE IN GAPS BETWEEN A MATTRESS THAT IS TOO SMALL OR TOO THICK AND CRIB SIDES.
- INFANTS CAN SUFFOCATE ON SOFT BEDDING. NEVER ADD A PILLOW OR COMFORTER. NEVER PLACE ADDITIONAL PADDING UNDER AN INFANT.

STRANGULATION HAZARD

- STRINGS CAN CAUSE STRANGULATION! DO NOT PLACE ITEMS WITH A STRING AROUND CHILD'S NECK, SUCH AS HOOD STRINGS OR PACIFIER CORDS. DO NOT SUSPEND STRINGS OVER A CRIB OR ATTACH STRINGS TO TOYS.
- TO PREVENT STRANGULATION, TIGHTEN ALL SCREWS AND BOLTS. A CHILD CAN TRAP PARTS OF THE BODY OR CLOTHING ON LOOSE SCREWS AND BOLTS.
- **DO NOT** PLACE CRIB NEAR A WINDOW WHERE CORDS FROM BLINDS OR DRAPES MAY STRANGLE A CHILD.

FALL HAZARD

- WHEN CHILD IS ABLE TO PULL TO A STANDING POSITION, SET MATTRESS TO LOWEST POSITION AND REMOVE BUMPER PADS, LARGE TOYS AND OTHER OBJECTS THAT COULD SERVE AS STEPS FOR CLIMBING OUT.
- WHEN CHILD IS ABLE TO CLIMB OUT OR REACHES THE HEIGHT OF 35 IN. (89CM), THE CRIB SHALL NO LONGER BE USED.

IMPORTANT!

- CHECK THIS CRIB FOR DAMAGED HARDWARE, LOOSE JOINTS, MISSING PARTS OR SHARP EDGES BEFORE AND AFTER ASSEMBLY AND FREQUENTLY DURING USE. **DO NOT** USE CRIB IF ANY PARTS ARE MISSING OR BROKEN. ASK YOUR DEALER OR CONTACT WESTWOOD DESIGN: 635 N. BILLY MITCHELL RD., STE. B, SALT LAKE CITY, UTAH 84108, PHONE: 1-908-719-4707, EMAIL: SUPPORT@WESTWOODBABY.COM; FOR REPLACEMENT PARTS AND INSTRUCTIONAL LITERATURE IF NEEDED. **DO NOT** SUBSTITUTE PARTS.

Congratulations on your purchase of a Westwood product. We take great pride in the quality and design of our furniture. The safety of your child is our highest priority. It is important that you read these instructions carefully and completely to ensure that this product functions as it was designed.

After opening the package, check to see that all the parts are present. If you think something is missing, please contact your retailer, and they can arrange to have the missing parts quickly replaced. You can also contact our spare parts hotline: 1-973-305-0444, or email parts@westwoodbaby.com.








If any aspect of these instructions is unclear, please contact your retailer or Westwood for assistance.

For general support and help questions, you can contact Westwood directly by calling 1-908-719-4707, or emailing support@westwoodbaby.com.










In addition to meeting our own extensive in-house testing and standards, this crib has been independently tested to meet JPMA certification standards.



Crib Parts:



Hardware (Enclosed in Bag):

<div>I</div> <div>8 x Barrel Nut</div> <div></div>	<div>J</div> <div>8 x Allen Bolt, 3-1/8" Long</div> <div></div>	
<div>K</div> <div>8 x Phillips Screw, 1-3/8" Long</div> <div></div>	<div>L</div> <div>8 x Wing Nut</div> <div></div>	
<div>N</div> <div>6 x Allen Bolt, 3" Long</div> <div></div>	<div>O</div> <div>6 x Allen Bolt, 2" Long</div> <div></div>	
<div>P</div> <div>6 x Allen Bolt, 1-1/8" Long</div> <div></div>	<div>Q</div> <div>6 x Cap Nut</div> <div></div>	<div>R</div> <div>Allen Wrench</div> <div></div>

Step 1

- A.** Position the stabilizer bars so that the four large holes face the inside of the crib. The two smaller holes for the spring deck should be at the top.
- B.** Place a barrel nut (I) in the hole, with the slot aligned horizontally.
- C.** Put the allen bolt (J) through the crib side and thread it into the barrel nut.
- D.** Use the allen wrench to securely tighten the bolt.
- E.** Repeat with the remaining 7 holes.


Required Hardware




8 x Barrel Nut **(I)**



8 x Allen Bolt, 3-1/8" Long **(J)**



Allen Wrench **(R)**



Step 2

- A.** Open all 4 support arms on the spring platform as shown in the drawing.
- B.** Place a screw through the stabilizer bar as shown, then through the support arm on the spring. Thread on a wing nut and tighten securely.
- C.** Repeat for the remaining three support arms.
- D.** Set the spring to the desired height by adjusting the support arms. The spring should be at its highest setting for newborns, then adjusted to the lower positions as the child grows and becomes mobile. Once the child is able to stand, the spring should be at its lowest position.
- E.** Insert a screw through the appropriate hole in the frame, then through the support arm, and thread on a wing nut, tightening it securely.
- F.** Repeat for the remaining three support arms.


Required Hardware



8 x Phillips Screw **(K)**



8 x Wing Nut **(L)**




Step 3

- A.** Thread the allen bolt (N) through the back of the headboard into the fitting on the back of the crib side. Tighten securely using the allen wrench.
- B.** Repeat for the other 5 holes.


Required Hardware



6 x Allen Bolt, 3" Long **(N)**



Allen Wrench **(R)**




Step 4

- A.** Thread the allen bolt (O) through the back of the corner post on the crib side into the fitting on the back of the footboard. Tighten securely using the allen wrench.
- B.** Repeat for the other 5 holes.


Required Hardware



6 x Allen Bolt, 2" Long (O)



Allen Wrench (R)





Allen Bolt (O)

Mattress Height Adjustment

As the child grows and becomes more mobile, the mattress support should be adjusted to a lower position. By the time the child can stand, the mattress should be in its lowest position.

- A.** Carefully tip the crib onto its back.
- B.** Undo the four wing nuts holding the support arms to the spring and remove the screws.
- C.** Lower the spring to the desired setting and align the holes.
- D.** Insert the screws and tighten the wing nuts.



Day Bed Conversion

- A.** Remove the 6 bolts attaching the footboard to the crib, and remove the footboard. Save all hardware for future reassembly of your crib.
- B.** Insert the allen bolt (P) through the hole in the corner post, and thread it into the cap nut as shown. Tighten securely using the allen wrench.
- C.** Repeat with the other 5 holes.


Required Hardware




6 x Allen Bolt, 1-1/8" Long **(P)**



6 x Cap Nut **(Q)**




Allen Wrench **(R)**



Care and Maintenance

- After completing assembly, check that all bolts and screws are secure and tight. Hardware can become loose over time, so it is your responsibility to periodically check the tightness of all fasteners for as long as you use the crib.
- Wood is a natural material. As such, it can be affected by changes in temperature and humidity. Extreme changes in humidity and temperature can cause the wood to warp, swell, crack, or shrink, thus compromising the structural integrity of the crib and making it dangerous to use.
- Use caution when placing the crib in storage to avoid extremes in temperature or humidity. Cribs should always be stored indoors in climate controlled, dry locations.
- Use care when using a vaporizer or humidifier around the crib. Do not aim the vapor at the crib or any other wooden furniture in the nursery. Avoid using vaporizers or humidifiers for extended periods of time.
- To clean the crib, wipe with a damp cloth and immediately dry the surface. Do not use any chemical cleaners or polishes. Such products can leave a residue on the finish and come in contact with your child.
- Your crib has a durable and protective non-toxic finish. However, if you decide to refinish it, you must use a non-toxic finish specified for children's products. Do not use any toxic stripping methods to remove the old finish.

November 29, 2010



635 N. Billy Mitchell Rd., Ste. B
Salt Lake City, UT 84116
Phone: 1-908-719-4707
support@westwoodbaby.com