




**Motor Protection Electronics, Inc.**  
 2464 Vulcan Rd. Apopka, Florida 32703  
**Phone:** 407-299-3825  
**Fax:** 407-294-9435  
**Email:** [info@mpeelectronics.com](mailto:info@mpeelectronics.com)  
**Website:** [www.mpeelectronics.com](http://www.mpeelectronics.com)

## SUMP AND SEWAGE PUMP EXERCISER® FOR INTEGRAL FLOAT OPERATED PUMPS

The Exerciser® reads the state of the Float Switch and turns the pump ON when the Float Switch closes, and turns the pump OFF when the Float Switch opens. If the pump has not run for 7 days, The Exerciser® will automatically exercise the pump for 3 seconds. The 7 day exercise time delay is reset each time the pump is called to run by the Float Switch.

The Exerciser® also detects if a foreign object is keeping the pump from turning freely by monitoring both the motor inrush current and the motor

[+ more](#)



1

<u>Item #</u>	<u>Description</u>	<u>Supply Voltage</u>	<u>Supply Phase</u>	<u>Supply Frequency</u>	<u>Maximum Power Consumption</u>
<u>SPEx-2</u>	Exerciser® Only	115 VAC ± 10 %	Single Phase	50/60 Hz	3.8 V·A
<u>SPEx-2MP</u>	Exerciser® and Mating Plug for Float Switch Receptacle. (No Float Switch)	115 VAC ± 10 %	Single Phase	50/60 Hz	3.8 V·A

<u>Item #</u>	<u>Description</u>	<u>Supply Voltage</u>	<u>Supply Phase</u>	<u>Supply Frequency</u>	<u>Maximum Power Consumption</u>
<u>SPEX-2FS</u>	Exerciser® and Float Switch with Mating Plug for Float Switch Receptacle.	115 VAC ± 10 %	Single Phase	50/60 Hz	3.8 V·A