

MAINTENANCE & WARRANTY

MAINTENANCE

Routine maintenance of the seatpost will provide years of trouble-free performance. Before and after every ride the stanchion (shiny shaft) of the dropper post should be cleaned of any dirt and debris. Ensure that nothing gets in the way of the dropper post during operation, if the stanchion is scratched or damaged the dropper post function could be affected.

Servicing: We recommend servicing the post after 6 months of regular use or 1 year of mild use. If you see any signs of stanchion scratching or feel any rough movement then it may be time for a service. Please use the 6 months as a rough guide, if you ride in severe conditions or ride very regularly then servicing may need to be more frequent

Service kits are available on our website. Dropper servicing should only be undertaken by skilled mechanics.

WARRANTY

This seatpost is warranted for a period of 2 years from the date of purchase against any physical failure or breakage from fatigue or poor workmanship.

Moving parts of the seatpost including the cartridge, seals, brass keys and bushings are warranted against defective workmanship for a period of 1 year. Wear and tear on such items is not warranted; these items should be replaced during servicing.

The warranty is expressly limited to the repair or replacement of the defective part at Lyne Components option and is the sole remedy of the warranty. The warranty applies only to the original owner and is not transferable. Proof of purchase is required to validate warranty eligibility. The warranty does not cover normal wear and tear, routine maintenance, improper installation or improper use of the seat post. Modification of the post in any manner will void the warranty. Lyne components will not be responsible for incidental or individual costs incurred that are not covered by this warranty. The user assumes the risk of any personal injury or property damage, including damage to the seatpost and any other losses.